

## ► Kontron User's Guide



## ► coolMonster/PM

Document Revision 1.13

Computer On  
Modules

Blades &  
Mezzanines

CPU  
Boards

Systems

Mobile  
Rugged

Custom  
Solutions



**kontron**



# Table of Contents

<b>1</b>	<b>User Information</b> .....	<b>6</b>
1.1	About This Document .....	6
1.2	Copyright Notice .....	6
1.3	Trademarks .....	6
1.4	Standards .....	6
1.5	Warranty .....	6
1.6	Technical Support.....	7
<b>2</b>	<b>Introduction</b> .....	<b>8</b>
2.1	coolMONSTER/PM .....	8
2.2	The coolMONSTER PISA® Family .....	8
<b>3</b>	<b>Getting started</b> .....	<b>9</b>
<b>4</b>	<b>Specifications</b> .....	<b>10</b>
4.1	Functional Specifications .....	10
4.2	Mechanical Specifications .....	12
4.2.1	PISA Bus Connector .....	12
4.2.2	Dimensions .....	12
4.2.3	Height on Top.....	12
4.2.4	Height on Bottom.....	12
4.2.5	Weight .....	12
4.3	Electrical Specifications.....	12
4.3.1	Supply Voltages .....	12
4.3.2	Supply Voltage Ripple .....	12
4.3.3	Supply Current (typical).....	12
4.3.4	Supply Current (maximum).....	13
4.3.5	Real-time Clock (RTC) Battery .....	14
4.4	MTBF.....	15
4.5	Environmental Specifications .....	15
4.5.1	Temperature.....	15
4.5.2	Humidity .....	15
<b>5</b>	<b>CPU, Chipset and Super I/O</b> .....	<b>16</b>
5.1	CPU .....	16
5.2	Chipset.....	16
5.2.1	GMCH (855GME Chipset) .....	16
5.2.2	ICH4 (82801DB).....	17
5.3	Super I/O.....	18
5.4	CPU, Chipset and Super-I/O Configuration.....	18

<b>6</b>	<b>System Memory</b> .....	<b>19</b>
<b>7</b>	<b>PISA Bus</b> .....	<b>20</b>
<b>8</b>	<b>Front Panel</b> .....	<b>21</b>
<b>9</b>	<b>Keyboard and Mouse Interface</b> .....	<b>22</b>
9.1	PS/2-Keyboard Connector .....	22
9.2	PS/2-Keyboard Configuration .....	22
9.3	PS/2-Mouse Connector .....	22
9.4	PS/2-Mouse Configuration .....	23
<b>10</b>	<b>USB INTERFACES</b> .....	<b>24</b>
10.1	Front Connectors ( USB 0 and USB 1) .....	24
10.2	Internal Connector (USB 2) .....	24
10.3	Configuration .....	24
<b>11</b>	<b>Ethernet INTERFACE</b> .....	<b>26</b>
11.1	Ethernet Controller.....	26
11.2	Connector .....	26
11.3	Configuration .....	27
11.4	Ethernet Technical Support .....	27
<b>12</b>	<b>Graphic Interfaces</b> .....	<b>28</b>
12.1	Video Controller .....	28
12.2	CRT Connector .....	28
12.3	DVO Connector.....	28
12.4	Flat Panel LVDS Interface (JILI) Connector .....	29
12.5	Display Power Considerations .....	30
12.6	Connecting a LCD Panel .....	30
12.7	Configuration .....	30
12.8	Graphics Technical Support .....	31
12.9	Available Video Modes.....	31
12.9.1	Standard IBM-Compatible VGA Modes.....	31
12.9.2	Extended VESA VGA Modes .....	31
<b>13</b>	<b>Serial-Communication Interfaces</b> .....	<b>33</b>
13.1	Serial Ports COMA to COMD .....	33
13.2	RS-232 Connectors .....	33
13.3	RS-485 Connector .....	34
13.4	Configuration .....	34
13.4.1	RS-485 Diagram .....	34

<b>14</b>	<b>Parallel-Port Interface .....</b>	<b>35</b>
14.1	Connector .....	35
14.2	Configuration .....	35
<b>15</b>	<b>EIDE Interfaces .....</b>	<b>36</b>
15.1	Connector .....	36
15.2	Configuration .....	36
15.3	Signal Descriptions.....	36
15.4	Configuration .....	36
15.4.1	Primary EIDE Pin-out.....	37
15.4.2	Secondary EIDE Pin-out .....	38
<b>16</b>	<b>Floppy Interface .....</b>	<b>39</b>
16.1	Connector .....	39
16.2	Configuration .....	39
<b>17</b>	<b>Sound Interface .....</b>	<b>40</b>
17.1	Connector .....	40
17.2	Configuration .....	41
17.3	Technical Support for Sound .....	41
<b>18</b>	<b>Feature Interface.....</b>	<b>42</b>
18.1	Connector .....	42
18.2	Configuration .....	42
18.3	Signal Description .....	42

# 1 User Information

## 1.1 About This Document

This document provides information about products from Kontron Embedded Modules GmbH and/or its subsidiaries. No warranty of suitability, purpose, or fitness is implied. While every attempt has been made to ensure that the information in this document is accurate, the information contained within is supplied "as-is" and is subject to change without notice.

For the circuits, descriptions and tables indicated, Kontron assumes no responsibility as far as patents or other rights of third parties are concerned.

## 1.2 Copyright Notice

Copyright © 2003-2007 Kontron Embedded Modules GmbH

All rights reserved. No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), without the express written permission of Kontron Embedded Modules GmbH.

DIMM-PC®, PISA®, ETX®, ETXexpress®, microETXexpress™, X-board®, DIMM-IO® and DIMM-BUS® are trademarks or registered trademarks of Kontron Embedded Modules GmbH. Kontron is trademark or registered trademark of Kontron AG.

## 1.3 Trademarks

The following lists the trademarks of components used in this board.

- IBM, XT, AT, PS/2 and Personal System/2 are trademarks of International Business Machines Corp.
- Microsoft is a registered trademark of Microsoft Corp.
- Intel is a registered trademark of Intel Corp.
- All other products and trademarks mentioned in this manual are trademarks of their respective owners.

## 1.4 Standards

Kontron Embedded Modules GmbH is certified to ISO 9000 standards.

## 1.5 Warranty

This Kontron Embedded Modules GmbH product is warranted against defects in material and workmanship for the warranty period from the date of shipment. During the warranty period, Kontron Embedded Modules GmbH will at its discretion decide to repair or replace defective products.

Within the warranty period, the repair of products is free of charge as long as warranty conditions are observed.

The warranty does not apply to defects resulting from improper or inadequate maintenance or handling by the buyer, unauthorized modification or misuse, operation outside of the product's environmental specifications or improper installation or maintenance.

Kontron Embedded Modules GmbH will not be responsible for any defects or damages to other products not supplied by Kontron Embedded Modules GmbH that are caused by a faulty Kontron Embedded Modules GmbH product.

## 1.6 Technical Support

Technicians and engineers from Kontron Embedded Modules GmbH and/or its subsidiaries are available for technical support. We are committed to making our product easy to use and will help you use our products in your systems.

Before contacting Kontron Embedded Modules GmbH technical support, please consult our Web site at <http://www.kontron-emea.com/emd> for the latest product documentation, utilities, and drivers. If the information does not help solve the problem, contact us by telephone or email.

Kontron Asia Inc.  
4F, No.415, Ti-Ding Blvd., NeiHu  
District,  
Taipei 114, Taiwan  
Tel: +886 2 2799 2789  
Fax: + 886 2 2799 7399  
<mailto:sales@kontron.com.tw>

Kontron Embedded Modules GmbH  
Brunnwiesenstr. 16  
94469 Deggendorf – Germany  
Tel: +49 (0) 991-37024-0  
Fax: +49 (0) 991-37024-333  
<mailto:sales-kem@kontron.com>

Kontron America  
14118 Stowe Drive  
Poway, CA 92064-7147  
Tel: +1 (888) 294 4558  
Fax: +1 (858) 677 0898  
<mailto:sales@us-kontron.com>

## 2 Introduction

### 2.1 coolMONSTER/PM

The coolMONSTER/PM hosts an Intel® Pentium® M processor in combination with an Intel® 855GME chipset with an integrated graphic memory controller hub. Celeron M versions of this board are possible, too. One DDR-SDRAM-DIMM socket for up to 1 GB allows you to use standard DDR DIMM memory modules. Three USB 2.0 ports and one 10/100 MBit Ethernet interface extend the standard connectivity of four serial, one parallel and a PS/2 mouse/keyboard interface.

The coolMONSTER/PM is designed in the PISA format, which provides the functionality of the PCI and ISA bus on one well-defined bus. To connect a backplane with a PISA board, you only need to use one EISA-like edge card connector. The pin-out of the upper row of the PISA bus connector corresponds to the pin-out of the ISA bus connector. The lower row provides PCI signals, which makes it easy to design backplanes with up to four PCI slots and additional ISA slots.

### 2.2 The coolMONSTER PISA® Family

coolMONSTER products represent the best scaleable half-size Slot SBC family. Each coolMONSTER module is characterized by the same mechanical and electrical pin-out for the Keyboard, COM A-D, EIDE 40pin and 44pin, LPT, LAN, VGA, USB, and Floppy. These homogeneous features facilitate easiest upgrades within the Kontron Embedded Modules GmbH coolMONSTER product family.

PISA® is the proven space saving concept that provides full PCI and ISA Bus signals on just half-size Slot boards. The ancestors were full-sized PICMG boards that have the PCI and ISA card edges in a row - PISA squeezed them to just half-size, still serving full PCI and ISA busses. Smaller and cheaper enclosures were possible that way - while all PCI and ISA periphery is maintained.

Whenever a LCD panel is required, coolMONSTER products with onboard graphics controllers serve as the right choice. Display connections are simplified when using these units, which come with a JUMPttec Intelligent LVDS Interface (JILI) or JUMPttec Intelligent Display Adaption (JIPA). The interface can recognize which display is connected and then independently set all video parameters.

As part of the standard features package, all coolMONSTER modules come with a JUMPttec Intelligent Device Architecture (JIDA) interface, which is integrated into the BIOS of the SBC modules. This interface enables hardware independent access to the coolMONSTER features that cannot be accessed via standard APIs. Functions such as watchdog timer, brightness and contrast of LCD backlight and user bytes in the EEPROM can be configured with ease by taking advantage of this standard coolMONSTER module feature.

## 3 Getting started

Getting started with the coolMONSTER/PM is very easy. For location of the connectors, see Appendix E: Connector Layout. Take the following steps:

- Turn off the power supply.
- Connect the power supply to the coolMONSTER's power supply connector or power the board through a backplane.
- Plug a memory module into the memory socket of the coolMONSTER/PM.
- Connect the CRT monitor to the CRT interface or a LCD panel to the JILI interface by using a corresponding adapter cable.
- Plug the keyboard and the mouse to the PS/2 connectors or use USB keyboard or mouse.
- Connect the floppy drive cable to the coolMONSTER's floppy interface. Attach the floppy drive to the connector at the opposite end of the cable.
- Connect the power supply to the floppy's power connector.
- Plug a hard-drive data cable to the coolMONSTER's hard-disk interface.
- Attach the hard disk to the connector at the opposite end of the cable.
- If necessary, connect the power supply to the hard disk's power connector.
- If required, plug a ISA or PCI extension card to the appropriate slot in the backplane
- Make sure all your connections have been made correctly.
- Turn on power.
- Enter the BIOS by pressing the F2 key during boot-up. Make all changes in the BIOS setup. See the BIOS chapter of this manual for details.

## 4 Specifications

### 4.1 Functional Specifications

#### Processor

- Intel® Pentium®-M 1.8GHz CPU 745
- Intel® Celeron® M 370 1.5GHz, 1MB L2 (socketed)
- Intel® Celeron®-M 1.0GHz ULV 373
- Intel® processor 800MHz, 0kBL2 cache
- CPU socket 479 supports all Pentium®-M in PGA package
- Further processor support planned

#### Chipset

- Intel® 855GME Chipset graphics memory controller hub

#### Power Supply

- 5V only supply
- Onboard power supply to low voltage technology

#### Super I/O

- SMSC SCH3114

#### Cache

- On-die second level cache between 512KB and 2MB depending on used CPU

#### Memory

- One 184-pin DIMM unbuffered DDR SDRAM, up to 1 GB (no ECC support)

#### Four Serial Ports (COM A to COM D)

- 3 RS232C serial ports (1 DSUB9 at the front, 3 internal, 10-pin headers)
- 16550 compatible
- COM D configurable as RS422/485

#### One Parallel Port (LPT1)

- Enhanced Parallel Port (EPP) and Extended Capabilities Port (ECP) with bi-directional capability

**Floppy Interface****Intelligent Drive Electronics (IDE)**

- Two UDMA Peripheral Component Inter-connect (PCI) Bus Master IDE port (each up to two devices)

**System Monitor Controller for Temperature and****Universal Serial Bus (USB)**

- 3 USB 2.0 ports (2 at the front, 1 internal on feature connector)
- USB legacy keyboard support
- USB-boot support

**Ethernet**

- Integrated Intel® 82562 10/100BASE-T LAN
- Follows the common criteria of the embedded technology market segment

**Onboard Video Graphics Array (VGA)**

- Intel® 855GM/GME Chipset graphics memory controller hub with Intel® Extreme Graphics 2 technology
- CRT (Cathode Ray Tube) and LCD flat panel LVDS interface (JILI)
- LCD (Liquid Crystal Display) flat panel 2x24bit LVDS interface that uses JILI

**Audio**

- Integrated in Intel® SoundBlaster™ AC97
- Windows Sound System™ compatible

**Phoenix BIOS, 1024KB Flash BIOS****NV-EEPROM for CMOS Setup Retention without Battery****PS/2 Keyboard Controller****PS/2 Mouse Controller****Watchdog timer (WDT)****Real Time Clock (RTC) with Onboard Battery Supply**

## 4.2 Mechanical Specifications

### 4.2.1 PISA Bus Connector

- Edge card connector, EISA standard, AMP 650226-1 (or compatible)

### 4.2.2 Dimensions

- Length x Width: 176 mm x 125mm (6.9" x 4.9")

### 4.2.3 Height on Top

- Ca 40 mm (1.6")
- Height is depending upon SDRAM module and CPU cooler/fan. This can block PCI or ISA slots on some backplanes.

### 4.2.4 Height on Bottom

- Maximum 4 mm (0.16")

### 4.2.5 Weight

- 320g (full featured version without SDRAM)

## 4.3 Electrical Specifications

### 4.3.1 Supply Voltages

- +5V DC +/- 5%
- Optional +5V DC Standby +/- 5%

### 4.3.2 Supply Voltage Ripple

- 100mV peak to peak 0 - 20MHz

### 4.3.3 Supply Current (typical)

The coolMONSTER/PM is equipped with power-saving features. Different power-consumption tests were executed to give an overview of the electrical conditions for several operational states. The board used a 1024MB DDR SDRAM module. The attached hard disk was not supplied through the measurement path and no extension card was attached to the system.

#### coolMONSTER/PM 1.0GHz (Celeron-M®)

	+5V only
DOS Prompt	2.6A
DOS Standby	1.7A
Windows Idle	1.8A
Windows Standby	0.7A

Windows 100% CPU Load	3.5A
-----------------------	------

### coolMONSTER/PM 1.8GHz

	+5V only
DOS Prompt	4.8A
DOS Standby	3.0A
Windows Idle	3,1A
Windows Standby	1,4A
Windows 100% CPU Load	6.7A

#### 4.3.4 Supply Current (maximum)

	+5V only
coolMONSTER/PM 1.0GHz	3.6A
coolMONSTER/PM 1.8GHz	7.1A

(calculated theoretical values from all components maximum supply currents)

### 4.3.5 Real-time Clock (RTC) Battery

- Voltage range: 1.8V - 4.0V (typ 3.0V)
- Quiescent current: max. 3,5uA@ 3.0 V

**English:**

**CAUTION !** *Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.*

**Deutsch:**

**VORSICHT !** *Explosionsgefahr bei unsachgemäßem Austausch der Batterie. Ersatz nur durch den selben oder einen vom Hersteller empfohlenen gleichwertigen Typ. Entsorgung gebrauchter Batterien nach Angaben des Herstellers.*

**French:**

**ATTENTION !** *Risque d'explosion avec l'échange inadéquat de la batterie. Remplacement seulement par le même ou un type équivalent recommandé par le producteur. L'évacuation des batteries usagées conformément à des indications du fabricant.*

**Danish:**

**ADVARSEL !** *Lithiumbatteri – Eksplosionsfare ved fejlagtig Håndtering. Udskifting må kun skedes med batteri af samme fabrikant og type. Lever det brugte batteri tilbage til leverandøren.*

**Finnish:**

**VAROITUS !** *Paristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainoastaan laltevalmistajan suosittelmaan tyyppiin. Havita käytetty paristo valmistajan ohjeiden mukaisesti.*

**Spanish:**

**Precaución !** *Peligro de explosión si la batería se sustituye incorrectamente. Sustituya solamente por el mismo o tipo equivalente recomendado por el fabricante. Disponga las baterías usadas según las instrucciones del fabricante.*

*The battery of this product is not considered to be accessible by the end user. Safety instructions are given only in English, German, French, Danish, Finish and Spanish. If the battery is accessible by the end user, it is in the responsibility of the customer to give the corresponding safety instructions in the required language(s).*

## 4.4 MTBF

The following MTBF (Mean Time Between Failure) values were calculated using a combination of manufacturer's test data, if the data was available, and a Bellcore calculation for the remaining parts. The Bellcore calculation used is "Method 1 Case 1". In that particular method the components are assumed to be operating at a 50 % stress level in a 40° C ambient environment and the system is assumed to have not been burned in. Manufacturer's data has been used wherever possible. The manufacturer's data, when used, is specified at 50° C, so in that sense the following results are slightly conservative. The MTBF values shown below are for a 40° C in an office or telecommunications environment. Higher temperatures and other environmental stresses (extreme altitude, vibration, salt water exposure, etc.) lower MTBF values.

**System MTBF (hours) : (171.636) TBD**

---

**Notes:** *Fans usually shipped with Kontron Embedded Modules GmbH products have 50,000-hour typical operating life. The above estimates assume no fan, but a passive heat sinking arrangement. Estimated RTC battery life (as opposed to battery failures) is not accounted for in the above figures and need to be considered for separately. Battery life depends on both temperature and operating conditions. When the Kontron unit has external power; the only battery drain is from leakage paths.*

---

## 4.5 Environmental Specifications

### 4.5.1 Temperature

The Intel® Mobile Pentium®-M is specified for proper operation when junction temperature is within the specified range of 0°C to 100°C.

The Intel® 855GM/GME Chipset temperature and the Intel® ICH4 I/O Controller Hub 4 (82801DB) case temperature are maximum 110°C.

- Operating: 0 to +60° C (\*) (with appropriate airflow)
- Non-operating: -10 to +85 °C (non-condensing)

---

**Note:** (\*) *The maximum operating temperature is the maximum measurable temperature on any spot on the module's surface. You must maintain the temperature according to the above specification.*

---

### 4.5.2 Humidity

- Operating: 10% to 90% (non-condensing)
- Non-operating: 5% to 95% (non-condensing)

## 5 CPU, Chipset and Super I/O

### 5.1 CPU

The coolMONSTER/PM is available with an Intel® Mobile Pentium®-M or Celeron®-M central processing unit (CPU) from 0.8GHz up to 1.8GHz. However, other GHz as well as Celeron®-M versions (half cache size, no SpeedStep® technology) of this board are available.

Intel® Mobile Pentium®-M CPU features include:

- Supports Intel® Architecture with Dynamic Execution
- High performance, low-power core
- On-die, primary 32-kbyte instruction cache and 32-kbyte write-back data cache
- On-die, up to 2-MByte (depends on CPU) second level cache with Advanced Transfer Cache Architecture
- Advanced Branch Prediction and Data Prefetch Logic
- Streaming SIMD Extensions 2 (SSE2)
- 400-MHz, Source-Synchronous processor system bus
- Advanced Power Management features, including Enhanced Intel SpeedStep® technology (only for Pentium® M processors)

### 5.2 Chipset

The chipset of the coolMONSTER/PM consists of the Intel® 855GME chipset GMCH (Graphics and Memory Controller Hub) and the Intel® 82801DB ICH-4 (I/O Controller Hub 4).

#### 5.2.1 GMCH (855GME Chipset)

##### Processor/Host Bus Support

- Intel® Pentium® M and Celeron® M processors
- Supports system bus at 400MHz
- Supports Enhanced Intel® SpeedStep® technology

##### Memory System

- Directly supports one DDR SDRAM channel, 64-bits wide
- Supports DDR 200/266/333-MHz SDRAM devices with double-sided DIMMs (four rows populated) with unbuffered PC1600/PC2100/PC2700 DDR SDRAM.
- Supports 128-Mbit, 256-Mbit, and 512-Mbit technologies providing maximum capacity of 1 GB with x16 devices
- All supported devices have four banks

**Internal Graphics Features**

- Up to 32MB of dynamic video memory allocation
- Display image rotation
- Graphics core frequency
- Display core frequency at 133MHz or 200MHz
- Render core frequency at 100MHz,133MHz, 200MHz
- 2D graphics engine
- 3D graphics engine
- Single- or dual-channel LVDS panel support up to UXGA panel resolution with frequency range from 25MHz to 112MHz (single channel/dual channel)

**Video Stream Decoder**

- Improved hardware motion compensation for MPEG2
- Software DVD at 60 Fields/second and 30 frames/second full screen
- Support for standard definition DVD (i.e. NTSC pixel resolution of 720x480, etc.)
- quality encoding at low CPU utilization

**Power Management**

- APM 1.2 compliant power management
- ACPI 1.0b, 2.0 support
- Enhanced Intel® SpeedStep Technology support

**5.2.2 ICH4 (82801DB)****PCI 2.2 Bus interface at 33MHz****Integrated LAN controller**

- WfM 2.0 and IEEE802.3 compliant with 10/100 Mbit/s Ethernet support

**USB**

- Two UHCI USB 1.1 or one EHCI high speed USB 2.0 host controller(s)
- Supporting up to 3 ports (2 available on the coolMONSTER board's slot connector, 1 on internal feature connector)

**AC-Link for AC'97 support****Integrated IDE controller**

- Ultra ATA/100/66/33 and PIO mode support
- Two channels for up to 4 devices with independent timing

- Support of “Native Mode” register and interrupts

#### **Interrupt Controller**

- Two cascade 83C59 with 15 interrupts
- Integrated I/O APIC capability with 24 interrupts

#### **Enhanced DMA**

- Two cascaded 8237 controllers
- Supports PC/PCI DMA and LPC DMA
- Supports DMA collection buffers

#### **Timers based on 82C54**

#### **Power Management Logic**

- ACPI 2.0 compliant
- Supports PCI PME#
- Low Pin Count (LPC) Interface
- SM Bus 2.0 interface (System Management Bus)

### **5.3 Super I/O**

The super I/O device is a SMSC SCH3114 that is connected to the LPC (Low Pin Count) Bus. This device provides the following additional features:

- Four serial ports (one port capable of RS422/RS485 functionality)
- One Multi-Mode Parallel Port
- Floppy Disk Controller
- PS/2-Keyboard Controller and PS/2-Mouse Interface
- 5V CPU Fan

### **5.4 CPU, Chipset and Super-I/O Configuration**

See the Advanced Menu and its submenus section of the Appendix B: BIOS chapter for information on possible settings.

## 6 System Memory

The coolMONSTER/PM supports 184-pin DIMM DDR-SDRAM memory modules. One socket is available for 2.5V (power level), unbuffered double data rate synchronous dynamic random access memory (DDR-SDRAM) up to 1024MB following Intel's DDR333/PC2700 Specification.

The supported devices on the DDR-SDRAM module must be 128-Mbit, 256-Mbit or 512-Mbit technologies chips. All modules validated by Intel with the 845 chipset and minimum DDR266 speed are electrical ready with the 855 chipset (A similar memory interface is used on the two chipsets.)

---

**Notes:** *Some older modules and modules out of specification are designed for 2.7V (power level). These modules may not work well at the coolMONSTER/PM.*

---

The total amount of memory available on the DDR-SDRAM modules is used for main memory and graphics memory on the coolMONSTER/PM. Unified Memory Architecture (UMA) manages the sharing of the system memory between the graphics controller and processor. Full system memory size is not available for software applications. Up to 32MB of system memory are used for graphics memory.

Memory modules with ECC are not supported.

## 7 PISA Bus


PISA® is the proven space saving concept that provides full PCI and ISA Bus signals on just half-size Slot boards. The edge card connector provides the ISA signals on the upper row and the PCI signals on the lower row and uses the same connector known from EISA systems.

A detailed description of the signals and its timing characteristics is beyond the scope of this document. Refer to the PISA specification PISAD?? (the three questionmarks holding the revision number) available on the Kontron web sites and the official ISA- and PCI-specifications for further details.

## 8 Front Panel

The coolMONSTER/PM comes with a front panel interface that provides the following connectivity:

- CRT interface
- Ethernet interface
- 2 USB2.0 ports
- PS/2 keyboard connector
- PS/2 mouse connector




## 9 Keyboard and Mouse Interface

The coolMONSTER/PM offers a PS/2-keyboard and PS/2-mouse interface on Connectors X15 and X16. The lower interface is for the Mouse and the upper interface for the Keyboard connection. To find the location of the keyboard and mouse connector, please see the Appendix E: Connector Layout chapter.

### 9.1 PS/2-Keyboard Connector

The following table shows the pin-out of the PS/2-keyboard connector on the front.

	1	KBDAT	PS/2 Keyboard data (bi-directional I/O)
	2	MSDAT	PS/2 Mouse data (bi-directional I/O)
	3	GND	Ground
	4	VCC *	+5V (max. current 500mA, shared with PS/2 Mouse Con)
	5	KBCLK	PS/2 Keyboard clock (bi-directional I/O)
	6	NC	PS/2 Mouse clock (bi-directional I/O)

---

**Notes:** (\*) To protect the external power lines of peripheral devices, make sure that:

- the wires have the right diameter to withstand the maximum available current
- the enclosure of the peripheral device fulfils the fire-protecting requirements of IEC/EN 60950.


---

### 9.2 PS/2-Keyboard Configuration

Refer to the Keyboard Features submenu and the I/O Device Configuration submenu in the Appendix B: BIOS chapter for information on configuration.

### 9.3 PS/2-Mouse Connector

The following table shows the pin-out of the PS/2-Mouse connector on the front.

	1	MSDAT	PS/2 Mouse data (bi-directional I/O)
	2	NC	Not connected
	3	GND	Ground
	4	VCC *	+5V (max. current 500mA, shared with PS/2 Keyboard Con)
	5	MSCLK	Mouse clock (bi-directional I/O)
	6	NC	Not connected

---

**Notes:** (\*) To protect the external power lines of peripheral devices, make sure that:

- the wires have the right diameter to withstand the maximum available current
- the enclosure of the peripheral device fulfils the fire-protecting requirements of IEC/EN 60950.

---

## 9.4 PS/2-Mouse Configuration


You can set the PS/2 mouse to enabled, disabled or auto-detect from the BIOS Setup. If you enable the mouse, IRQ12 is used as the interrupt and is no longer available for other devices. Please refer to the Miscellaneous Submenu in the Appendix B: BIOS chapter for additional information on configuration.

## 10 USB INTERFACES

The coolMONSTER/PM offers 3 USB ports. These ports are driven by either two UHCI USB 1.1 or one EHCI USB 2.0 controller(s). Two of the three USB ports are available on the coolMONSTER/PM's slot connector, and one more port es available on the internal feature connector. You can expand the ports for up to 127 USB peripherals by using external USB hubs.

### 10.1 Front Connectors ( USB 0 and USB 1)

The two USB interfaces on the front are available through Connectors X3 and X13. To find the location of the USB connectors, please see the Appendix E: Connector Layout chapter. The following table shows the pin-out of these USB interfaces.



1	USB_5V *	USB-supply (max. 500mA)
2	USB-	Universal serial bus port (-)
3	USB+	Universal serial bus port (+)
4	USB_GND	USB Ground

---

**Notes:** (\*) *To protect the external power lines of peripheral devices, make sure that:*

- *the wires have the right diameter to withstand the maximum available current*
- *the enclosure of the peripheral device fulfils the fire-protecting requirements of IEC/EN 60950.*

*The USB power lines are protected with a resettable fuse and are limited to 500mA*

---

### 10.2 Internal Connector (USB 2)

The internal USB interface is available through the feature Connector X12. To find the location and Pin-Out of the USB connector, please see the Appendix E: Connector Layout chapter.

#### Limitations of USB Port 2

There are no dedicated Pins for USB power. When using this USB port the user must make sure that a power supply is used which monitors the drawn current and limits it to 500mA, otherwise a defective USB device may damage the coolMONSTER/PM. Kontron recommends using a resettable fuse, which follows the USB 1.1 specification, for power on external USB connectors.

### 10.3 Configuration

You can enable or disable the two USB UHCI Host Controllers in the BIOS Setup Utility for support of USB 1.1 devices. USB Host Controller 1 serves the two USB Ports 0 and 1 on the front. USB host Controller 2 serves the USB Port 2 on the feature connector.

For high-speed USB 2.0 support of all 3 available ports, enable the USB EHCI Host Controller.

You also can enable or disable the legacy USB support. Legacy support is required for a USB keyboard and a USB Mouse when used with non USB aware operating systems such as Unix or DOS. It also is

required to boot from USB mass storage devices. For more information, see the I/O Device Configuration Submenu section in Appendix B: BIOS Operation.

You can download available drivers or get driver download support information from the Kontron Web site. Kontron offers the latest Kontron-tested drivers, which can differ from newer ones. For further technical questions, contact your local support or get support information and downloadable software updates from Intel®.

---

**Notes:** 1. *Some operating systems without USB 2.0 support do not work well with EHCI controller enabled. If you install such an OS at the coolMONSTER/PM please disable the EHCI controller in the Setup Utility before installation.*

2. *For operating systems not listed on our Web site please contact your OS distributor for an USB 2.0 driver. We are not allowed by law to ship USB 2.0 drivers.*

---

# 11 Ethernet INTERFACE

The coolMONSTER/PM comes with one Ethernet interface, which uses the ICH4's integrated 32-bit PCI LAN controller in combination with the Intel® 82562 platform LAN connect device. The network controller supports a 10/100Base-T interface. The device auto-negotiates the use of a 10Mbit/sec or 100Mbit/sec connection.

All major network-operating systems and several real-time and embedded operating systems support the interface.

## 11.1 Ethernet Controller

The Intel® 82562 features are:

- IEEE 802.3 10Base-T/100Base-TX compliant physical layer interface
- IEEE 802.3u Auto-Negotiation support
- IEEE 802.3x Full Duplex Flow Control standard
- Digital Adaptive Equalization control
- Link status interrupt capability
- 10Base-T auto-polarity correction
- Platform LAN connect interface support
- Diagnostic loopback mode
- 1:1 transmit transformer ratio support
- Low power (less than 300mW in active transmit mode)
- Reduced power in "unplugged mode"

---

**Note:** *The Ethernet interface works according to the common criteria of the embedded technology market segment.*


---

## 11.2 Connector

The 10/100Base-T interface is available on a standard 8-pin RJ45 jack. It is available at the slot panel of the coolMONSTER/PM through Connector X7.

To find the location of the Ethernet interface, please see the Appendix E: Connector Layout chapter.

The following table shows the pin-out of the Ethernet connector.



1	TXD+	100/10BASE-T Transmit	Differential Output
2	TXD-	100/10BASE-T Transmit	Differential Output
3	RXD+	100/10BASE-T Receive	Differential Input
4	NC **	For internal use only	
5	NC **	For internal use only	
6	RXD-	100/10BASE-T Receive	Differential Input
7	NC **	For internal use only	
8	NC **	For internal use only	

L	Left LED	Activity	Green
R	Right LED	Link	Yellow

**NOTE:** (\*\*) Do not connect anything to these pins!

### 11.3 Configuration

The onboard LAN controller can be enabled or disabled in the BIOS Setup Utility. Additionally it is possible to enable the onboard LAN PXE boot ROM to allow the system to boot up via a network connection from a PXE boot server. Refer to the I/O Device Configuration Submenu in the Appendix B: BIOS Operation chapter for additional information on configuration.

You can download available drivers from the Kontron Web site. For further information read the read-me file or contact technical support.

### 11.4 Ethernet Technical Support

If any problems occur, you can solve some of them by using the latest drivers for the Intel® LAN controller. Kontron provides you with the latest Kontron-tested drivers, which can differ from newer ones. For further technical support, contact either Kontron or get support information and downloadable software updates from Intel®.

## 12 Graphic Interfaces

### 12.1 Video Controller

The coolMONSTER/PM uses the graphics accelerator integrated in the Intel® 855GM/GME chipset, which delivers high-performance 2D, 3D and video capabilities. With its interface to UMA (Unified Memory Architecture) up to 32MB of system memory are used as video memory.


The controller can drive four interfaces with its two graphic engines on the coolMONSTER/PM:

- Cathode Ray Tube (CRT) interface
- Low Voltage Differential Signaling (LVDS) interface
- 2 Digital Video Output (DVO) ports

### 12.2 CRT Connector

The CRT (Cathode Ray Tube) interface is available through a standard DSUB15 connector X9, which is located at the slot connector.

The following table shows the pin-out of the CRT connector.

	1	RED	Red Video
	2	GRN	Green Video
	3	BLU	Blue Video
	4	NC	Not connected
	5	GND	Ground
	6	GND	Ground
	7	GND	Ground
	8	GND	Ground
	9	NC	Not connected
	10	GND	Ground
	11	NC	Not connected
	12	DDA	DDC Serial Data Line
	13	HSYNC	Horizontal Sync
	14	VSYNC	Vertical Sync
	15	DCK	DDC Data Clock Line

To find the location of the CRT interface, please see the Appendix E: Connector Layout chapter.

### 12.3 DVO Connector

The DVO (Digital Video Output) interface is available on Connector X1, a 50-pin, flat-foil connector on the bottom side of the board. To find the location of the DVO interface, please see the Appendix E: Connector Layout chapter. DVO interface usage excludes LVDS interface usage.

The following table shows the pin-out of the DVO connector.

1	DVOCDO	Channel-C / Data 0	2	DVOBDO	Channel-B / Data 0
---	--------	--------------------	---	--------	--------------------

3	DVOCD1	Channel-C / Data 1	4	VCC	+5V Power
5	DVOBD1	Channel-B / Data 1	6	DVOCD2	Channel-C / Data 2
7	DVOBD2	Channel-B / Data 2	8	VCC	+5V Power
9	DVOCD3	Channel-C / Data 3	10	DVOBD3	Channel-B / Data 3
11	DVOCD4	Channel-C / Data 4	12	GND	Ground
13	DVOBD4	Channel-B / Data 4	14	DVOCD5	Channel-C / Data 5
15	DVOBD5	Channel-B / Data 5	16	GND	Ground
17	DVOCD6	Channel-C / Data 6	18	DVOBD6	Channel-B / Data 6
19	DVOCD7	Channel-C / Data 7	20	GND	Ground
21	DVOBD7	Channel-B / Data 7	22	DVOCD8	Channel-C / Data 8
23	DVOBD8	Channel-B / Data 8	24	GND	Ground
25	DVOCD9	Channel-C / Data 9	26	DVOBD9	Channel-B / Data 9
27	DVOCD10	Channel-C / Data 10	28	GND	Ground
29	DVOBD10	Channel-B / Data 10	30	DVOCD11	Channel-C / Data 11
31	DVOBD11	Channel-B / Data 11	32	GND	Ground
33	DVOBCLK	Channel-B / Clock Out 0	34	DVOBCLK# (*)	Channel-B / Clock Out 1
35	GND	Ground	36	DVOCCLK	Channel-C / Clock Out 0
37	DVOCCLK# (*)	Channel-C / Clock Out 1	38	GND	Ground
39	DVOBVSNC	Channel-B Vertical Sync	40	DVOBHSYNC	Channel-B Horiz. Sync
41	DVOBBLANK#	Channel-B Flicker Blank	42	DVOBFLDSTL	Channel-B Field Stall
43	DVOCVSNC	Channel-C Vertical Sync	44	DVOCHSYNC	Channel-C Horiz. Sync
45	DVOCBLANK#	Channel-C Flicker Blank	46	DVOCFLDSTL	Channel-C Field Stall
47	DVOINT	LCD Interrupt	48	LTVDAT	LCD/TV Data
49	LTVCLK	LCD/TV Clock	50	VREF	Reference Voltage

(\*) optional

## 12.4 Flat Panel LVDS Interface (JILI) Connector

The interface for the LCD Panel is available through the X10 connector (40 pins) on the bottom side of the board. This connector represents the JILI interface (JUMPtect Intelligent LVDS Interface). The implementation of this subsystem complies with the JILI Specification of Kontron Embedded Modules GmbH. The coolMONSTER/PM already supports the JILI3 implementation. A variety of cables for different display types are available from Kontron. Please refer to the cable list on the Kontron Web site for part numbers and cable names. A detailed description of the JILI interface standard also is available in a separate document JILIM???.PDF. The three question marks represent the document's revision number. You can download the document from the Kontron Web site, or contact your local Kontron technical support to receive it.

To find the location of the LCD Panel interface connector, please see the Appendix E: Connector Layout chapter.

## 12.5 Display Power Considerations

When using a LCD Panel, additional voltages may be required to drive the display's logic and to supply the backlight converter and the display's contrast voltage.

The display logic may require +5V for standard or +3.3V for low-power LCDs. Contrast voltages for passive displays are normally very different and can range from -30V to +30V. Backlight converters usually are +5V or +12V types. When using a Kontron JILI cable, you do not need to determine such configurations. Display logic voltage and contrast voltage come pre-configured on the JILI cable. On occasion, backlight voltage has to be adjusted on the cable.

Even though the coolMONSTER/PM is also available as a +5V-only board, you need to supply the +12V for the backlight converter additionally when using such a converter type.

The onboard 3.3V-circuitry of the coolMONSTER/PM and the +3.3V logic voltage of low-voltage panels are powered by separate voltage regulators. The one for the LCD is mounted on the JILI adapter cable.

## 12.6 Connecting a LCD Panel

To determine whether your panel display is supported, check the Kontron Web site for panel lists. We regularly update the list of panels that have been tested with our boards.

Many panel adapters for a wide spread variety of displays are available through Kontron. If you use one of those adapters supplied by Kontron, configuration is easy:

- Check whether you have the correct adapter and cable for the panel you plan to use. Inspect the cable for damages.
- Disconnect the power from your system.
- Connect the panel adapter to the LCD Panel connector (JILI) on the coolMONSTER/PM.
- Connect the other end of the cable to your display.
- Connect the backlight converter.
- Supply power to your system.
- If no image appears on your display, connect a CRT monitor to the CRT connector.
- If necessary program the EEPROM on the JILI cable with the matching configuration data.
- If you still do not see improvement, consider contacting the dealer for technical support.

## 12.7 Configuration

You can set the general configuration for the graphic controller in the BIOS setup utility. Refer to the Advanced Chipset Control submenu and the Display Control submenu in the Appendix B: BIOS Operation chapter for more configuration information.

You can download drivers for the graphics controller from the Kontron Web site. For further information, read the read-me or help files or contact technical support.

## 12.8 Graphics Technical Support

If problems occur, you can solve some of them by using the latest drivers for the graphics controller. Kontron provides you with the latest tested drivers, which can differ from newer ones. For further technical support, contact either Kontron, or obtain support information and downloadable software updates from Intel®.

## 12.9 Available Video Modes

The following list shows the video modes supported by the graphics controller with maximum frame buffer size. When configured for smaller frame buffers and/or using a LCD panel on the JILI interface, not all of the video modes listed below may be available. Capability depends on system configuration and on display capabilities. Different operating systems also may not support all listed modes by the available drivers.

### 12.9.1 Standard IBM-Compatible VGA Modes

00h/01h	Text	40x25	16
02h/03h	Text	80x25	16
04h/05h	Graphics	320x200	4
06h	Graphics	640x200	2
0Dh	Graphics	320x200	16
0Eh	Graphics	640x200	16
0Fh	Graphics	640x350	Mono
10h	Graphics	640x350	16
11h	Graphics	640x480	2
12h	Graphics	640x480	16
13h	Graphics	320x200	256

### 12.9.2 Extended VESA VGA Modes

101h	Graphics	640x480	256
103h	Graphics	800x600	256
105h	Graphics	1024x768	256
107h	Graphics	1280x1024	256
111h	Graphics	640x480	64K
112h	Graphics	640x480	16M
114h	Graphics	800x600	64K
115h	Graphics	800x600	16M
117h	Graphics	1024x768	64K
118h	Graphics	1024x768	16M
11Ah	Graphics	1280x1024	64K
11Bh	Graphics	1280x1024	16M
13Ah	Graphics	1600x1200	256
13Ch	Graphics	1920x1440	256
14Bh	Graphics	1600x1200	64K

14Dh	Graphics	1920x1440	64K
15Ah	Graphics	1600x1200	16M
15Ch	Graphics	1920x1440	16M

## 13 Serial-Communication Interfaces

### 13.1 Serial Ports COMA to COMD


Four fully functional serial ports (COM A, COM B, COM C, and COM D) provide asynchronous serial communications. The serial ports support RS-232 operation modes and are compatible with the serial-port implementation used on the IBM Serial Adapter. You also can use COM D for RS-422/485 communications. The ports are 16550 high-speed UART compatible and support 16-byte FIFO buffers for transfer rates up to 115.2Kbaud. All COM ports are available on internal connectors.

COM A is available through the standard DSUB9 connector, which is part of the multi-function Connector X1 on the front. COM B to COM D are available through Connectors X15, X16 and X17 (10 pins in line). To find the location of the serial ports on the board, please see the Appendix E: Connector Layout chapter.

### 13.2 RS-232 Connectors

The following table shows the pin-out of COM A.

COM A to COM D are available through Connectors X18, X19, X20 and X21. To have the signals available on the standard serial interface connectors DSUB9 or DSUB25, an adapter cable is required. A 9-pin DSUB cable is available from Kontron (KAB-DSUB9-2, Part Number 96017-0000-00-0).

	1	DCD1/2/3/4	Data Carrier Detect	In
	2	DSR1/2/3/4	Receive Data	In
	3	SIN1/2/3/4	Transmit Data	Out
	4	RTS1/2/3/4	Data Terminal Ready	Out
	5	SOUT1/2/3/4	Signal Ground	--
	6	CTS1/2/3/4	Data Set Ready	In
	7	DTR1/2/3/4	Request to Send	Out
	8	RI1/2/3/4	Clear to Send	In
	9	GND	Ring Indicator	--
	10	VCC*	+5V	--

---

**Notes:** (\*) To protect the external power lines of peripheral devices, make sure that:


- the wires have the right diameter to withstand the maximum available current
- the enclosure of the peripheral device fulfils the fire-protecting requirements of IEC/EN 60950.

---

To find the location of the serial ports on the board, please see the Appendix E: Connector Layout chapter.

### 13.3 RS-485 Connector

You can use Connector X17 (COM D) for RS422/485 purposes.




The serial port COM D can only be used either as RS232 (Connector X21) or as RS422/RS485 (Connector X17).

### 13.4 Configuration

From the BIOS set-up utility, you can set the serial input/output interfaces to enabled, disabled or auto. The base I/O-addresses 3F8h, 2F8h, 3E8h, or 2E8h can be configured when enabled, as well as the interrupts IRQ3, IRQ4, IRQ10 and IRQ11. COM D can be set to the RS232 or RS485 interface. Refer to the I/O Device Configuration submenu in the Appendix B: BIOS Operation chapter for information on configuration.

#### 13.4.1 RS-485 Diagram



## 14 Parallel-Port Interface

The coolMONSTER/PM incorporates an IBM XT/AT compatible parallel port. It supports uni-directional, bi-directional, EPP and ECP operating modes.

### 14.1 Connector

The parallel port is available through connector X11 (26 pins). To have the signals available on a standard, parallel-interface connector DSUB-25, an adapter cable is required, which is available from KONTRON (KAB-DSUB25-1, Part Number 96015-0000-00-0).

The following table shows the pin-out as well as necessary connections for a DSUB-25 adapter.

	1	/STB	Strobe	Out	1
	3	PD0	Data 0	I/O	2
	5	PD1	Data 1	I/O	3
	7	PD2	Data 2	I/O	4
	9	PD3	Data 3	I/O	5
	11	PD4	Data 4	I/O	6
	13	PD5	Data 5	I/O	7
	15	PD6	Data 6	I/O	8
	17	PD7	Data 7	I/O	9
	19	/ACK	Acknowledge	In	10
	21	/BUSY	Busy	In	11
	23	PE	Paper out	In	12
	25	/SLCT	Select out	In	13
	2	/AFD	Autofeed	Out	14
	4	/ERR	Error	In	15
	6	/INIT	Init	Out	16
	8	/SLIN	Select in	Out	17
	26	VCC *	+ 5 V	--	NC
	10,12	GND	Signal Ground	--	18 - 25
	14,16	GND	Signal Ground	--	18 - 25
	18,20	GND	Signal Ground	--	18 - 25
	22,24	GND	Signal Ground	--	18 - 25

**Notes:** (\*) To protect the external power lines of peripheral devices, make sure that:

- the wires have the right diameter to withstand the maximum available current
- the enclosure of the peripheral device fulfils the fire-protecting requirements of IEC/EN 60950.

To find the location of the parallel port, please see the Appendix E: Connector Layout chapter.

### 14.2 Configuration

The parallel-port mode, I/O addresses, and IRQs are changeable from the BIOS Setup Utility. You can program the base I/O-address 378h (default), 3BCh or 278h. You can set the parallel port mode to disable, enable or AUTO (default). You can choose IRQ5 or IRQ7 as the parallel-port interrupt.

Refer to the I/O Device Configuration Submenu in the Appendix B: BIOS Operation chapter for additional information on configuration.

## 15 EIDE Interfaces

PCI-bus devices serve as primary and secondary IDE hosts on the coolMONSTER/PM. The controller supports:

- Up to Ultra DMA 100 mode
- Up to PIO mode 4 timing
- Multiword DMA mode 1 and 2 with independent timing

The controller also supports IDE legacy and IDE native mode configuration. The coolMONSTER/PM features two IDE interfaces that can drive four hard-disk drives. When two IDE devices share a single adapter, they are connected in a master/slave, daisy-chain configuration. If only one drive is in the system, you must set it as the master.

### 15.1 Connector

IDE interface 1 is available through Connector X4 (39 pins). This interface is designed in 0.1" grid for optimal connectivity to a 3.5" hard drive. IDE interface 2 is available through Connector X6 (44 pins.) It is designed in a 2mm grid for optimal connectivity to a 2.5" hard drive.

There are several accessories available for IDE interface 2 connectivity.

You can use two cables to directly connect a hard disk in a 2.5" form factor (KAB-IDE-2MM, Part Number 96021-0000-00-0) or a 3.5" form factor (KAB-IDE-25, Part Number 96020-0000-00-0).

### 15.2 Configuration

The EIDE interfaces offer several configuration settings. Refer to the Main Menu and I/O Device Configuration Submenu and the Master or Slave Submenu in the Appendix B: BIOS Operation chapter for additional information on configuration.

### 15.3 Signal Descriptions

#### HDRSTJ (Reset)

- The reset signal is active low during power up and inactive thereafter.

#### DASP\_P, DASP\_S (Primary, secondary master/slave select)

- This signal drives a LED whenever a connected hard disk is being accessed or when a second drive is present. This signal is active low when the hard disk is busy.

### 15.4 Configuration

The EIDE interfaces offer several configuration settings. Refer to the Main Menu and I/O Device Configuration Submenu and the Master or Slave Submenu in the Appendix B: BIOS Operation chapter for additional information on configuration.

### 15.4.1 Primary EIDE Pin-out

	1	/HDRST	Reset
	2	GND	Ground
	3-18	PIDE_D1..D15	Primary IDE ATA data bus
	19	GND	Ground
	21	PIDE_DRQ	Primary IDE DMA Request for IDE master
	22	GND	Ground
	23	/PIDE_IOW	Primary IDE IOWJ Command
	24	GND	Ground
	25	/PIDE_IOR	Primary IDE IORJ Command
	26	GND	Ground
	27	PIDE_RDY	Primary IDE ready
	28	PIDE_PD1	IDE1 Cable Select (470Ω to Ground)
	29	/PIDE_AK	Primary IDE DACK for IDE master
	30	GND	Ground
	31	PIDE_IRQ	IDE IRQ Primary
	32	NC	Not connected
	33	PIDE_A1	Primary IDE ATA address bus
	34	PIDE_ATAD	UDMA detection
	35	PIDE_A0	Primary IDE ATA address bus
	36	PIDE_A2	Primary IDE ATA address bus
37	/PIDE_CS1	IDE chipselect 1 for primary channel 0	
38	/PIDE_CS3	IDE chipselect 2 for primary channel 1	
39	PIDE_ACT	Drive Activity	
40	GND	Ground	

To find the location of IDE interface, please see the Appendix E: Connector Layout chapter.

---

**Notes:**

1. Use an UDMA flat-ribbon cable (80 lines) to drive UDMA66 or UDMA100 devices
2. When using a standard ribbon cable (40 lines) with UDMA66 or UDMA100 devices, you have to disable the Ultra DMA Mode in the BIOS Setup Utility.

---

## 15.4.2 Secondary EIDE Pin-out

1	2	1	HDRSTJ	Reset
		2	GND	Ground
		3-18	SIDE_D1..D15	Secondary IDE ATA data bus
		19	GND	Ground
		20	NC	Not connected
		21	SIDE_DRQ	Secondary IDE DMA Request for IDE master
		22	GND	Ground
		23	SIDE_IOWJ	Secondary IDE IOWJ Command
		24	GND	Ground
		25	SIDE_IORJ	Secondary IDE IORJ Command
		26	GND	Ground
		27	SIDE_RDY	Secondary IDE ready
		28	SEC_PD1	IDE2 Cable Select (470Ω to Ground)
		29	SIDE_AKJ	Secondary IDE DACKJ for IDE master
		30	GND	Ground
		31	SIRQII	IDE IRQ Secondary
		32	NC	Not connected
		33	SIDE_A1	Secondary IDE ATA address bus
		34	NC	Not connected
		35	SIDE_A0	Secondary IDE ATA address bus
		36	SIDE_A2	Secondary IDE ATA address bus
		37	SIDE_CS1J	IDE chipselect 1 for secondary channel 0
		38	SIDE_CS3J	IDE chipselect 2 for secondary channel 1
		39	DASP_S	Secondary master/slave select
		40	GND	Ground
		41	VCC *	+5V
		42	VCC *	+5V
		43	GND	Ground
		44	NC	Not connected

**Notes:** (\*) To protect the external power lines of peripheral devices, make sure that:  
 -- the wires have the right diameter to withstand the maximum available current  
 -- the enclosure of the peripheral device fulfils the fire-protecting requirements of IEC/EN 60950.

To find the location of EIDE-controller interfaces 2, please see the Appendix E: Connector Layout chapter.


## 16 Floppy Interface

The floppy-drive interface of the coolMONSTER/PM uses a 2.88MB super I/O floppy-disk controller and can support two floppy disk drives with densities that range from 360kB to 2.88MB.

### 16.1 Connector

The floppy disk interface is available on Connector X14 (34 pins).

The following table shows the connector pin-out.

	1	GND	Ground	2	RPM	Density select
	3	GND	Ground	4	NC	Not connected
	5	GND	Ground	6	NC	Not connected
	7	GND	Ground	8	INDEXJ	Index
	9	GND	Ground	10	MTR0J	Motor on 0
	11	GND	Ground	12	DR1J	Drive select 1
	13	GND	Ground	14	DR0J	Drive select 0
	15	GND	Ground	16	MTR1J	Motor on 1
	17	GND	Ground	18	FDIR	Direction
	19	GND	Ground	20	STEPJ	Step
	21	GND	Ground	22	WDATAJ	Write data
	23	GND	Ground	24	WGATEJ	Write gate
	25	GND	Ground	26	TRK0J	Track 0
	27	GND	Ground	28	WRTPRTJ	Write protect
	29	GND	Ground	30	RDATAJ	Read data
	31	GND	Ground	32	HDSEL	Head select
	33	GND	Ground	34	DSKCHG	Disk change

To find the location of floppy-drive interface, please see the Appendix E: Connector Layout chapter.

**Notes:** (\*) To protect the external power lines of peripheral devices, make sure that:

- the wires have the right diameter to withstand the maximum available current
- the enclosure of the peripheral device fulfils the fire-protecting requirements of IEC/EN 60950.

### 16.2 Configuration

You can configure the floppy disk interface in the BIOS Setup Utility. You can choose the 3.5" (common) or 5.25" drive types with densities of 360kB, 720kB, 1.2MB, 1.25MB, 1.44MB or 2.88MB. Refer to the Main Menu section of the Appendix B: BIOS Operation chapter for more information on configuring the floppy drive.

You also can disable the floppy-disk interface in the I/O Device Configuration Submenu.

## 17 Sound Interface

The coolMONSTER/PM uses a Realtek ALC650 sound codec. The ALC650 is an 18-bit, full duplex AC'97 2.2 compatible stereo audio CODEC designed for PC multimedia systems, including host/soft audio and AMR/CNR based designs. The ALC650 incorporates proprietary converter technology to achieve a high SNR, greater than 90 dB.

All major operating systems support the interface.


The ALC650 features:

- High-performance CODEC with high S/N ratio (>90 dB)
- 18-bit ADC and 20-bit DAC resolution
- Compliant with AC'97 2.2 Specifications
- 18-bit stereo full-duplex CODEC with independent and variable sampling rate
- One analog line-level stereo input with 5-bit volume control: LINE\_IN, (CD\_IN is possible)
- Stereo Output with 5-bit volume control
- MIC input
- Power-management capabilities
- Embedded 50mW/20ohm OP at front LINE output

### 17.1 Connector

The sound connector is available through Connector X8 (6 pins).

The following table shows the pin-out of the connector.

	1	RECHTS	Line-level stereo output right.
	2	ASGND	Analog ground.
	3	LINKS	Line-level stereo output left.
	4	AUXAR_C	Auxiliary A input right. Normally intended for connection to an internal or external CD-ROM analog output.
	5	MIC_C	Mono Microphone input.
	6	AUXAL_C	Auxiliary A input left. Normally intended for connection to an internal or external CD-ROM analog output.

To find this connector on the board and for mating connector information see Appendix E: Connector Layout.

## 17.2 Configuration

From the BIOS Setup Utility you can set the onboard legacy AC97 audio controller to Disabled or Enabled (default). Refer to I/O Device Configuration submenu in the Appendix B: BIOS operation for more details.

You can download available drivers for the sound controller from the Kontron Web site or use the drivers provided by the manufacturer Realtek. Search for ALC650 drivers for the required operating.

## 17.3 Technical Support for Sound

If problems occur, you can solve some of them by using the latest drivers for the Sound controller. Kontron provides you with the latest tested drivers, which can differ from newer ones. For further technical support, contact either Kontron, or obtain support information and downloadable software updates from Realtek.

# 18 Feature Interface

## 18.1 Connector

The feature connector is available through the X12 connector (26 pins) and controls functions such as the PS/2 keyboard clock and data, hard-disk LED, USB serial bus ports, and various ATX power signals.

The following table shows the pin-out of the connector.

1	KBCLK	PS/2 Keyboard clock	2	MSCLK	PS/2 Mouse clock
3	KBDAT	PS/2 Keyboard data	4	MSDAT	PS/2 Mouse data
5	VCC *	+5V	6	NC	For internal use only!
7	NC	For internal use only!	8	GND	Ground
9	H_LED	Hard-disk LED	10	NC	For internal use only!
11	NC	For internal use only!	12	SPEAKER	Speaker out
13	NC	For internal use only!	14	NC	For internal use only!
15	GND	Ground	16	RESIN	Reset input
17	NC	For internal use only!	18	NC	For internal use only!
19	5V_SB	ATX standby supply	20	LILED	Link integrity LED
21	PS-ON	ATX power on signal	22	SPEEDLED	Speed LED
23	PWRBTN	ATX power button	24	ACTLED	Activity LED
25	USB2-	Universal serial bus port 2 (-)	26	USB2+	Universal serial bus port 2 (+)

---

**Notes:** (\*) To protect the external power lines of peripheral devices, make sure that:

- the wires have the right diameter to withstand the maximum available current
- the enclosure of the peripheral device fulfils the fire-protecting requirements of IEC/EN 60950.

The current of the pins on this connector is limited to 0.5A.

---

## 18.2 Configuration

You cannot configure the Feature interface from the BIOS Setup Utility.

## 18.3 Signal Description

### KBCLK/KBDAT/MSCLK/MSDAT

- Keyboard and PS/2 mouse data and clock signal.  
Do not use the keyboard and the mouse signals at the same time as the signals on the front bracket.

### H\_LED (Hard-disk LED)

- Signal shows activity on primary and secondary IDE drive. Connect the cathode of the LED to the H\_LED pin and the anode of the LED to the VCC supply voltage pin. The required 470R resistor is already mounted on board of the coolMONSTER/VC and coolMONSTER/VE.

**SPEAKER (Speaker Out)**

- This pin controls the speaker output. Connect the loudspeaker between this pin and GND.

**RESIN (Reset Input)**

- You can use this pin as a low active hardware reset. Connect with GND to force a system hard reset condition.

**LILED (Link Integrity LED)**

- This pin indicates link integrity on the LAN. If the link is valid in either 10 or 100 MPS, the LED is on; if link is invalid, the LED is off. Connect the LILED pin with the cathode of a LED. Connect the anode of the LED via a 470R resistor to VCC supply voltage. The 470R resistor is not onboard of the coolMONSTER/PM.

**SPEEDLED (Speed LED)**

- This pin indicates the speed of the LAN. The LED will be on at 100MPS and off at 10MPS. Connect the SPEEDLED pin with the cathode of a LED. Connect the anode of the LED via a 470R resistor to VCC supply voltage. The 470R resistor is not onboard of the coolMONSTER/PM.

**ACTLED (Activity LED)**

- This pin indicates either transmit or receive activity. When activity is present, the activity LED is on; when no activity is present, the LED is off. Connect the ACTLED pin with the cathode of a LED. Connect the anode of the LED via a 470R resistor to VCC supply voltage. The 470R resistor is not onboard of the coolMONSTER/PM.

**USB2-/USB2+ (Universal Serial Bus Port 2 -/+)**


- This is the serial data pair for USB Port 2 (controller 1).

**5V\_SB, PS-ON, PWRBTN (ATX Power Support Signals)**

For ATX support please connect the signals in the following manner:

- Connect Pin 19 of feature connector X12 with Pin 9 of ATX power connector (5V standby).
- Connect Pin 21 of feature connector X12 with Pin 14 of ATX power connector (power supply on).

When connected in the following manner, (Pin 23 of feature connector X12 – Button power on), you can switch the board on with the key T1 and switch it off by using the power down option implanted in the particular OS such as Windows 9X.



**NC (Internal Use Only!)**


- Do not connect any connector to this pin. Otherwise you could create a hazard to the system, make the system unstable, or even destroy it.

## 19 Fan Interface

The coolMONSTER/PM is normally shipped with a CPU fan. If for any reason no CPU fan is mounted or a different fan has to be used, use this interface to connect a fan to cool the CPU. The connector and onboard system controller support speed monitoring of the fan. This connector supports 5V fans, only

### 19.1 CPU Fan Connector

The CPU fan interface is available on connector X24 (3 pins).

Header	Pin	Signal Description	Function
	1	Sense	Speed Monitoring
	2	VCC *	+5V
	3	GND	Ground

---

**Notes:** (\*) To protect the external power lines of peripheral devices, make sure that:

- the wires have the right diameter to withstand the maximum available current
- the enclosure of the peripheral device fulfils the fire-protecting requirements of IEC/EN 60950.

---

For the location of the CPU fan connector see Appendix E: Connector Layout.

### 19.2 CPU Fan Configuration

You can set the active trip point to a value from 40°C up to 100°C in the ACPI Control submenu of the BIOS Setup Utility. The fan will automatically turn on whenever this trip point temperature value is reached. Setting this item to disabled means the fan will always run, except when the operating system takes control over it.

## 20 Power Interface


The coolMONSTER/PM is not a replacement for a power supply. It is a +5V only boards. Additional voltages (+12V, -12V, and -5V as well as +3.3V for external PCI-devices) are not generated onboard. If peripheral devices require these voltages, they have to be supplied through the backplane and the PISA bus.

In some applications, the COOLMONSTER-PM is intended for use as a stand-alone module without a backplane. You need to have a power connector available on the boards for direct power supply.

Power signals on the feature connector (X12) are not meant for power supply purpose.

### 20.1 Connector

The power connector is available through connector X23 (5 pins) and allows to supply +5V and +12V to the system. For ATX power supply signals refer to additional information in the Feature Connector section.

Header	Pin	Signal Name	Function
	1	+12V	+12V
	2	VCC *	+5V
	3	VCC *	+5V
	4	GND	Ground
	5	GND	Ground

**Notes:** (\*) To protect the external power lines of peripheral devices, make sure that:

- the wires have the right diameter to withstand the maximum available current
  - the enclosure of the peripheral device fulfils the fire-protecting requirements of IEC/EN 60950.
- The current of the pins on this connector is limited to 7A/pin.

The connector is from manufacturer MOLEX. To find the location of the connector and get information about mating connector see Appendix E: Connector Layout.

### 20.2 Configuration

The coolMONSTER/PM is equipped with a power management system. You can configure lots of options for power-saving states such as standby state with partial power reduction and suspend state with full-power reduction. You can specify wake-up events that bring the system back to full-on state. Please refer to the Power menu section in the Appendix B: BIOS Operation chapter for more information about power savings.

## 21 Watchdog Timer

The watchdog timer is integrated in the onboard SMSC SCH3114 controller of the coolMONSTER/PM and can issue a reset to the system or generate a non-maskable interrupt (NMI). The watchdog timer circuit has to be triggered within a specified time by the application software. If the watchdog is not triggered because proper software execution fails or a hardware malfunction occurs, it will reset the system or generate the NMI.

### 21.1 Configuration

You can set the watchdog timer to disabled, reset or NMI mode. You can specify the delay time and the timeout (trigger period) from 1 second to 30 minutes. The delay time is the time after first initialization before the trigger period starts. The timeout is the time the watchdog has to be triggered within. You can make the initialization settings in the BIOS setup. Refer to the Watchdog Settings Submenu in the Appendix B: BIOS Operation chapter for information on configuration.

### 21.2 Programming

#### 21.2.1 Initialization

You can initialize the watchdog timer from the BIOS setup. You also can set up the initialization from the application software with help of the JIDA (Jumptec Intelligent Device Architecture) programmer's interface.

#### 21.2.2 Trigger

The watchdog needs to be triggered out of the application software within a specified timeout period. You can only do this in the application software with help of the JIDA programmer's interface.

For information about the JIDA programmer's interface refer to the JIDA BIOS extension section in the Appendix B: BIOS chapter and separate documents available in the JIDA software packages on the Kontron Web site.

## 22 Hardware Monitor

The SMSC SCH3114 controller monitors several critical hardware parameters of the system, including power-supply voltages, fan speed and CPU temperature, which are very important for a high-end computer system to remain stable and properly. This controller is connected via the system management (SM) bus to the south bridge.

The following parameters are monitored:

- +3.3V from onboard DC/DC
- CPU core voltage
- +5V standby voltage
- Battery voltage
- CPU temperature with on-die diode
- CPU fan speed

### 22.1 Configuration

You can use the Hardware Monitor submenu in the BIOS Setup Utility to obtain information on voltages, fan speed and to check the temperature of the CPU die. For more information on this submenu, see the Appendix B: BIOS Operation chapter in this manual.

To monitor the parameters of this feature from your operating system, Kontron recommends that you use the 32-bit protected mode JUMPtéc's Intelligent Device Architecture 32-bit driver (JIDA 32) with the test and demo application for Windows 95/98/ME/NT/2000/XP, which is available on the Kontron Web site.

## 23 Important Technology Information

The following technological information is designed to give you a better understanding of some of the features offered by the coolMONSTER/PM. This information can be referenced when reading the Appendix A: System Resource Allocations and Appendix B: BIOS Operation sections that follow. There also are references to additional documentation that will help you develop a better understanding of the technical information. They are listed in the Appendix F: PC-Architecture Information.

### 23.1 Max CPU Frequency setting

Kontron Embedded Modules currently offers four variants of the coolMONSTER/PM. They are the 1800MHz Pentium® M versions and the 800MHz, 1000MHz or 1500MHz Celeron®-M version. Additional processor support is planned. These variants use a smart BIOS with the capability of identifying the CPU that the module is equipped with. Another feature of the BIOS is its ability to offer the user the option to set the maximum CPU frequency based on the Intel® SpeedStep® technology.

---

**Note:** Celeron® M processors do not support this feature.

---

The different Max CPU frequency settings available for the different modules are as follows:

- 800MHz: 800MHz
- 1000MHz: 1000MHz
- 1500MHz: 1500MHz
- 1800MHz: **600, 800, 1000, 1200, 1400, 1600, 1800MHz** (def)

---

**Notes:** Selecting frequencies higher than the default may cause the system to reach "Critical Trip Point" and shutdown if a proper cooling solution is not used. Always ensure that you use a proper cooling when selecting higher frequency settings.

---

Refer to the Power Menu section in the Appendix B: BIOS Operation chapter of this manual for more information.

### 23.2 Thermal Monitor and Catastrophic Thermal Protection

#### 23.2.1 Thermal Monitor

The Thermal Monitor within the Pentium M processor helps to control the processor temperature by activating the TCC (Thermal Control Circuit) when the processor silicon reaches its maximum operating temperature. The temperature at which the Intel Thermal Monitor activates the TCC is not user-configurable and is not software visible.

The Thermal Monitor controls the processor temperature by modulating (starting and stopping) the CPU core clocks at a 50% duty cycle (TM1) or by initiating an Enhanced Intel SpeedStep® technology transition (TM2\*) when the processor silicon reaches its maximum operating temperature. The mode is selectable in the BIOS Setup Utility.

- Maximum operating temperature activating TCC: 100°C

---

**Notes:** (\*) TM2 is the recommended mode for the Intel Pentium M processor.  
TM2 is not supported on boards with Celeron® M processor.

---

Thermal Monitor supports two modes to activate the TCC: Automatic and On-Demand mode. The Intel Thermal Monitor Automatic Mode must be enabled via BIOS for the processor to be operating within specification. Automatic mode does not require any additional hardware, software drivers, or interrupt handling routines.

### 23.2.2 Catastrophic Thermal Protection

The Intel Pentium M processor supports the THERMTRIP# signal for catastrophic thermal protection.

In the event of a catastrophic cooling failure, the processor will automatically shut down when the silicon has reached the absolute maximum temperature. At this point the system BUS signal THERMTRIP# will go active. THERMTRIP# activation is independent of processor activity and does not generate any bus cycles. The system will immediately shut down.

---

<i>Absolute maximum temperature activating THERMTRIP#:</i>	<i>125°C</i>
--	--------------

---

For more details, see Chapter 5.1.2 of the Intel Pentium M Processor Datasheet.

### 23.3 Processor Performance Control

The Pentium M processor can run in different performance states (multiple frequency/voltage operating points). The CPU performance can be altered while the computer is functioning. This allows the processor to run at different core frequencies and voltages depending on CPU thermal state and OS policy.

Microsoft Windows XP includes built-in processor performance control to operate the processor more efficiently when it is not fully utilized. Win2k, WinME and Win9x do not support processor performance control. Special software is required for Operating Systems that are not capable of processor performance control.

In Windows, the processor performance control policy is linked to the Power Scheme setting in the control panel power option applet.

---

**Notes:** *Windows always runs at the highest performance state when the "Home/Office" or the "Always On" power scheme is selected. For more detailed information about processor performance control, see:*

- Chapter 8 of the ACPI Specification Revision 2.0c
- Windows platform design notes

---

### 23.4 Thermal Management

ACPI allows the OS to play a role in the thermal management of the system. With the OS in control of the operating environment, cooling decisions can be made based on the application load on the CPU and the thermal heuristics of the system.

The ACPI thermal solution on coolMONSTER/PM supports three cooling policies and their trip points:

### Active Trip Point

Active cooling devices typically consume power and produce noise but are able to cool a thermal zone without limiting system performance. The active cooling trip point declares the temperature threshold OS uses to start/stop active cooling devices (fan).

### Passive Cooling Trip Point


Passive cooling devices produce no noise, but may not be effective enough to cool the thermal zone. The passive cooling trip point declares the temperature threshold in which the OS will start or stop passive cooling. In this case it throttles the processor.

### Critical Trip Point

The OS performs an orderly, but critical, shutdown of the system when the temperature reaches the critical trip point.

### Processor Clock Throttling

The ACPI OS assesses the optimum CPU performance change necessary to lower the temperature using the following equation:



$$\Delta P[\%] = TC1(T_n - T_{n-1}) + TC2(T_n - T_t)$$

$\Delta P$  is the performance delta,  $T_t$  is the target temperature = critical trip point. The two coefficients  $TC1$  and  $TC2$  and the sampling period  $TSP$  are hardware dependent constants that you must supply. (See the setup options in the ACPI Control Submenu section in the BIOS Operation chapter).

It is up to you to set the cooling preference of the system by setting the appropriate trip points in the BIOS setup.

---

*Notes: For more detailed information see Chapter 12 of the ACPI Specification.*

---

## 23.5 I/O APIC vs. 8259 PIC Interrupt mode

The I/O APIC (Advanced Programmable Interrupt Controller) handles interrupts differently than the 8259 PIC. Enable the I/O APIC mode in the BIOS Setup Utility, if your operating system supports it.

The following information explains these differences to the standard 8259 PIC mode:

### Method of interrupts transmission

- The I/O APIC transmits interrupts through the system bus and interrupts are handled without the needs for the processor to run an interrupt acknowledge cycle.

### Interrupt priority

- The priority of interrupts in the I/O APIC is independent of the interrupt number.

### More interrupts

- The I/O APIC in the chipset of the coolMONSTER/PM supports a total of 24 interrupts.

---

**Notes:** *The APIC is not supported by all operating systems. Only Windows XP supports APIC. The APIC mode must be enabled in the BIOS setup before the OS installation. APIC only works in ACPI mode. For more detailed information about APIC, see Chapter 8 of the IA-32 Intel Architecture Software Developer's Manual, Volume 3.*

---

## 23.6 Native vs. compatible IDE mode

### 23.6.1 Compatible IDE Mode

The ATA controller emulates a legacy IDE controller, which is a non-standard extension of the ISA-based IDE controller. In compatible mode, the controller requires two ISA IRQs (14 and 15) that cannot be shared with other devices.

### 23.6.2 Native Mode

The ATA controller acts as a true PCI device that does not require dedicated legacy resources and can be configured anywhere in the system. ATA controllers running in native mode use their PCI interrupt for both channels and can share this interrupt pin with other devices in the system, like any other PCI device.

By requiring only one shareable interrupt instead of two non-shareable ones, native-mode controllers significantly decrease the likelihood that a user will install a device that cannot work because no interrupts are available.

Enable Native IDE Support in the BIOS Setup Utility if your OS supports this mode.

---

**Notes:** *The Native Mode is not supported by all operating systems. The Native mode must be enabled in the BIOS setup before the OS installation. Native Mode only works in ACPI mode. For more information see: Microsoft Windows platform design notes about Native-mode ATA.*

---

### 23.6.3 Native Mode Configuration

Windows XP SP1 and Windows Server 2003 will switch a native-mode-capable ATA controller from compatible to native mode if the BIOS indicates that the controller can be switched, the controller supports native mode and the appropriate registry entry is set.

You must add a DWORD VALUE called EnableNativeModeATA under

**HKEY\_LOCAL\_MACHINE/System/CurrentControlSet/Control/PnP/PCI/**

and set 1 as the value.

## 24 Appendix A: System Resource Allocation

### 24.1 Interrupt Request (IRQ) Lines

In 8259 PIC mode (I/O APIC mode is disabled)

IRQ #	Use	Available	Comment
0	Timer0	No	
1	Keyboard	No	
2	Slave 8259	No	
3	COM2	No	Note (1)
4	COM1	No	Note (1)
5	Sound	No	Note (1), Note (2)
6	FDC	No	Note (1)
7	LPT1	No	Note (1)
8	RTC	No	
9	SCI	Yes	Note (3)
10	COM4	No	Note (1)
11	COM3	No	Note (1)
12	PS/2 Mouse	No	Note (1)
13	FPU	No	
14	IDE0	No	Note (1)
15	IDE1	No	Note (1)

---

**Notes:** (1) If the „used for“-device is disabled in setup, the corresponding interrupt is available for other devices.  
 (2) Possible setting for LPT1. IRQ7 is the default setting.  
 (3) Available in default configuration. IRQ 9 is used as SCI, if ACPI is enabled.

---

In I/O APIC mode

IRQ #	Use	Available	Comment
0	Timer0	No	
1	Keyboard	No	
2	Slave 8259	No	
3	COM2	No	Note (1)
4	COM1	No	Note (1)
5	Sound	No	Note (1), Note (2)
6	FDC	No	Note (1)
7	LPT1	No	Note (1)
8	RTC	No	
9	SCI	Yes	Note (3)
10	COM4	No	Note (1)
11	COM3	No	Note (1)
12	PS/2 Mouse	No	Note (1)
13	FPU	No	
14	IDE0	No	Note (1), Note (5)
15	IDE1	No	Note (1), Note (5)
16	PIRQ[A]	For PCI	

17	PIRQ[B]	For PCI	
18	PIRQ[C]	For PCI	
19	PIRQ[D]	For PCI	
20	PIRQ[E]	No	
21	PIRQ[F]	No	
22	PIRQ[G]	No	
23	PIRQ[H]	No	

**Notes:** (1) If the „used for“-device is disabled in setup, the corresponding interrupt is available for other devices.  
 (2) Possible setting for LPT1. IRQ7 is the default setting.  
 (3) Available in default configuration. IRQ 9 is used as SCI, if ACPI is enabled.  
 (5) Available if IDE controller is in Native Mode.

## 24.2 Direct Memory Access (DMA) Channels

DMA #	Use	Available	Comment
0		Yes	
1	Sound	No	Note (1), (2)
2	FDC	No	Note (1)
3		Yes	Note (2)
4	Cascade	No	
5		Yes	
6		Yes	
7		Yes	

**Notes:** (1) If the „used for“-device is disabled in setup, the corresponding DMA channel is available for other devices.  
 (2) Possible setting for LPT1 if configured for ECP mode.

## 24.3 Memory Map

The coolMONSTER/PM processor modules can support up to 2048MB of memory. The first 640KB of DDR-SDRAM are used as main memory.

Using DOS, you can address 1MB of memory directly. Memory area above 1MB (high memory, extended memory) is accessed under DOS via special drivers such as HIMEM.SYS and EMM386.EXE, which are part of the operating system. Please refer to the operating system documentation or special textbooks for information about HIMEM.SYS and EMM386.EXE.

Other operating systems (Linux or Windows versions) allow you to address the full memory area directly.

Upper Memory	Use	Available	Comment
A0000h – BFFFFh	VGA Memory	No	Mainly used by graphic adapter cards. If a PCI graphic card is in the system this memory area is mapped to the PCI bus.
C0000h – CFFFFh	VGA BIOS, RPL/PXE ROM	No	
D0000h – DFFFFh		Yes	Free for LPC bus or shadow RAM in standard

			configurations. If JRC software is used, a 16K block is shadowed for BIOS extension, starting with first free area at D0000h, D4000h, D8000h or DC000h. (BIOS extensions do not use the whole shadow block.)
F0000h – FFFFFh	System BIOS, USB legacy support	No	

### 24.3.1 Using Expanded Memory Managers

coolMONSTER/PM extension BIOSes may be mapped to an upper memory area. (See the previous table). Some add-on boards also have optional ROMs or use drivers that communicate with their corresponding devices via memory mapped I/O such as dual-ported RAM. These boards have to share the upper memory area with the Expanded Memory Manager's EMS frame. This often causes several problems in the system.

Most EMMs scan the upper memory area for extension BIOSes (optional ROMs) and choose a free memory area for their frame if it is not explicitly set. Normally, they are not always capable of detecting special memory-mapped I/O areas. You need to tell the EMM which memory areas are not available for the EMS frames, which is most of the time done by using special exclusion parameters.

If the Expanded Memory Manager you use cannot detect extension BIOSes (optional ROMs), make sure you excluded all areas in the upper memory, which are used by extension BIOSes, too. Your instruction in the CONFIG.SYS concerning the Expanded Memory Manager should look like this: (question marks symbolize the location of extension BIOS).

MS-DOS Example

```
DEVICE=EMM386.EXE X=????-???? X=E000-FFFF
```

---

**Note:** When booting up your system using this configuration under MS-DOS, the exclusion of area F000 to FFFF causes a warning. Microsoft reports that this message will always appear when the F000 segment lies in the shadow RAM. This is a bug of EMM386, not of the coolMONSTER/PM.

---

Please read the technical manuals of add-on cards used with the coolMONSTER/PM for the memory areas they use. If necessary, exclude their memory locations to avoid a conflict with EMM386.

## 24.4 I/O Address Map

The I/O-port addresses of the coolMONSTER/PM are functionally identical with a standard PC/AT. All addresses not mentioned in this table should be available. We recommend that you do not use I/O addresses below 0110hex with additional hardware for compatibility reasons, even if available.

Address (h)	Use	Available	Comment
0000 – 001F	DMA Controller 1	No	Fixed
0020 – 003D	Interrupt Controller 1	No	Fixed
0040 – 0053	Timer, Counter	No	Fixed
0060 – 0067	Keyboard controller	No	Fixed
0070 – 0077	Real Time Clock and CMOS Registers	No	Fixed
0080 – 008F	DMA Page Register	No	Fixed
0090 – 009F	DMA Control	No	Fixed
0092	Reset Generator	No	Fixed
00A0 – 00BF	Interrupt Controller 2	No	Fixed
00C0 – 00DF	DMA Controller 2	No	Fixed
00F0	Math. Coprocessor	No	Fixed
0100 – 010F	General Purpose I/O	No	Kontron Control Port, Fixed
0170 – 0177	Hard Disk Drive (Secondary)	No	Available if IDE port 2 is disabled or in native IDE mode
01F0 – 01F7	Hard Disk Drive (Primary)	No	Available if IDE port 1 is disabled or in native IDE mode
0220 – 0227	COM3	Yes	Possible address for COM
0228 – 022F	COM4	Yes	Possible address for COM
0274 – 0277	ISA PNP Data	No	Fixed
0278 – 027F	LPT	Yes	Possible address for LPT
02F8 – 02FF	COM2	Yes	Possible address for COM
0330 – 0331			
0376	IDE Controller	No	Available if IDE port 2 is disabled or in native IDE mode
0378 – 037F	LPT	No	Available if LPT is disabled
03BC – 03C3	LPT	Yes	Possible address for LPT
03B0 – 03DF	Graphic Subsystem	No	Fixed
03F6	IDE Controller	No	Available if IDE port 2 is disabled or in native IDE mode
03F0 – 03F7	Floppy Controller	No	Available if floppy controller is disabled
03F8 – 03FF	COM1	No	Available if COM is disabled
0400 – 047F	SIO Runtime Regs	No	Fixed
04D0 – 04D1	Interrupt Select	No	Fixed
0CF8 – 0CFF	PCI Configuration	No	Fixed
1000 – 107F	System Resources	No	Fixed
1180 – 11BF	System Resources	No	Fixed
1454	System Resources	No	Fixed
14D4	System Resources	No	Fixed
1500 – 157F	System Resources	No	Fixed
1800 – 1807	Graphic Subsystem	No	Fixed
1C00 – 1C1F	USB Host Controller 1	No	Fixed
2000 – 201F	USB Host Controller 2	No	Fixed
2400 – 240F	Ultra ATA Storage Controller	No	Fixed
2800 – 281F	SM-Bus Controller	No	Fixed
4000 – 403F	Ethernet Controller 2	No	Set at runtime
4400 – 443F	Ethernet Controller 1	No	Set at runtime

## 24.5 Peripheral Component Interconnect (PCI) Devices

All devices follow the PCI 2.1 specification. The BIOS and OS control memory and I/O resources. Please refer to the PCI 2.1 specification for details.

PCI Device (IDSEL)	PCI IRQ	REQ/ GNT	Comment
AGP Graphic	-	-	Separate Bus, integrated in Intel chipset
Ethernet (AD24)	INTE#	Discrete channel	
AC97 Sound	INTB#		Separate Bus, integrated in Intel chipset
1 <sup>st</sup> UHCI USB Controller	INTA#	-	Separate Bus, integrated in Intel chipset
2 <sup>nd</sup> UHCI USB Controller	INTD#	-	Separate Bus, integrated in Intel chipset
EHCI USB Controller	INTH#	-	Separate Bus, integrated in Intel chipset
PCI to ISA bridge (AD18)	-	REQ#4/GNT#4	

## 25 Appendix B: BIOS Operation

The coolMONSTER/PM comes with Phoenix BIOS 4.0, Release 6.1, which is located in the onboard Flash EEPROM in compressed form. The device has an 8-bit access. The shadow RAM feature offers faster access (16 bit). You can update the BIOS using a Flash utility. For complete Phoenix BIOS 4.0 information, visit the Phoenix Technologies Web site.

### 25.1 Determining the BIOS Version

To determine the BIOS version of the coolMONSTER/PM, immediately press the <Pause/Break> key on your keyboard as soon as you see the following text display in the upper left corner of your screen:

```
PhoenixBIOS 4.0 Release 6.1
Copyright 1985-2005 Phoenix Technology Ltd.

All Rights Reserved
Kontron(R) BIOS Version <LEUBR110>
Copyright 2002-2006 Kontron Embedded Modules GmbH
```

Whenever you contact technical support about BIOS issues, providing a BIOS version <LEUBR??> is especially helpful.

The system BIOS provides additional information about the board's serial number, CPU, and memory information by displaying information similar to the following:

```
S/N: YE5100002

CPU = Mobile Genuine Intel processor 1600MHz
503M System RAM Passed
1024K Cache SRAM Passed
System BIOS shadowed
Video BIOS shadowed
UMB upper limit segment address: E4EC
```

The board's serial number has value to technical support. coolMONSTER/PM serial numbers always start with YE and are followed by six or seven digits. The first digit represents the year of manufacturing, the next two digits stand for the lot number, and the last three or four digits are the number of the board in that lot.

In the example above, the board with the serial number YE5100002 was manufactured in year 2005, lot 10 of that year, and is board number 2 of that lot.

## 25.2 Configuring the System BIOS

The Phoenix BIOS setup utility allows you to change system behavior by modifying the BIOS configuration. Setup-utility menus allow you to make changes and turn features on or off.

BIOS setup menus represent those found in most models of the coolMONSTER/PM. The BIOS setup utility for specific models can differ slightly.

---

**Note:** *Selecting incorrect values can cause system boot failure. Load setup-default values to recover by pressing <F9>.*

---

### 25.2.1 Start Phoenix BIOS Setup Utility

To start the Phoenix BIOS Setup Utility, press the <F2> key when the following string appears during boot up.

Press <F2> to enter Setup

The Main Menu then appears.

### 25.2.2 General Information

The Setup Screen is composed of several sections:

Setup Screen	Location	Function
Menu Bar	Top	Lists and selects all top-level menus.
Legend Bar	Bottom	Lists setup navigation keys.
Item Specific Help Window	Right	Help for selected item.
Menu Window	Left Center	Selection fields for current menu.
General Help Window	Overlay (center)	Help for selected menu.

#### Menu Bar

The menu bar at the top of the window lists different menus. Use the left/right arrow keys to make a selection.

#### Legend Bar

Use the keys listed in the legend bar on the bottom to make your selections or exit the current menu. The table below describes the legend keys and their alternates.

Key	Function
<F1> or <Alt-H>	General Help window.
<Esc>	Exit menu.
← or → Arrow key	Select a menu.
↑ or ↓ Arrow key	Select fields in current menu.
<Tab> or <Shift-Tab>	Cycle cursor up and down.
<Home> or <End>	Move cursor to top or bottom of current window.
<PgUp> or <PgDn>	Move cursor to next or previous page.
<F5> or <->	Select previous value for the current field.
<F6> or <+> or <Space>	Select next value for the current field.

<F9>	Load the default configuration values for this menu.
<F10>	Save and exit.
<Enter>	Execute command or select submenu.
<Alt-R>	Refresh screen.

### Selecting an Item

Use the ↑ or ↓ key to move the cursor to the field you want. Then use the + and – keys to select a value for that field. Save Value commands in the Exit menu save the values displayed in all menus.

### Displaying Submenus

Use the ← or → key to move the cursor to the submenu you want. Then press <Enter>. A pointer ( ▶ ) marks all submenus.

### Item Specific Help Window

The Help window on the right side of each menu displays the Help text for the selected item. It updates as you move the cursor to each field.

### General Help Window

Pressing <F1> or <Alt-F1> on a menu brings up the General Help window that describes the legend keys and their alternates. Press <Esc> to exit the General Help window.

## 25.3 Main Menu

Feature	Option	Description
System Time	HH:MM:SS	Sets system time. Press <Enter> to move to MM or SS.
System Date	MM/DD/YYYY	Sets the system date. Press <Enter> to move to DD or YYYY.
Legacy Diskette A	360 Kb, 5 ¼ " 1.2 MB, 5 ¼ " 720 Kb, 3 ½ " <b>1.44/1.25 MB, 3 ½ "</b> 2.88 MB, 3 ½ " Disabled	Select the type of floppy disk drive.
Legacy Diskette B	360 Kb, 5 ¼ " 1.2 MB, 5 ¼ " 720 Kb, 3 ½ " 1.44/1.25 MB, 3 ½ " 2.88 MB, 3 ½ " <b>Disabled</b>	Select the type of floppy disk drive.
▸ Primary Master	Autodetected drive	Displays result of PM autotyping.
▸ Primary Slave	Autodetected drive	Displays result of PS autotyping.
▸ Compact Flash	Autodetected drive	Displays result of CF autotyping.
Smart Device Monitoring	Disabled <b>Enabled</b>	Turns on Self-Monitoring Analysis-Reporting Technology, which monitors the condition of the hard drive and reports when a catastrophic IDE failure is about to happen.
System Memory	N/A	Displays amount of conventional memory detected during bootup.
Extended Memory *	N/A	Displays amount of extended memory detected during bootup.

**Notes:** In the Option column, bold shows default settings.

(\*) Extended Memory = capacity of memory module – selected frame buffer memory size

### 25.3.1 Master or Slave Submenus

Feature	Option	Description
Type	None User <b>Auto</b> CD-ROM IDE Removable ATAPI Removable Other ATAPI	None = Autotyping is not able to supply the drive type or end user has selected None, disabling any drive that may be installed. User = End user supplies hdd information. Auto = Autotyping. The drive itself supplies the information. CD-ROM = CD-ROM drive. ATAPI Removable = Read- and writeable media e.g. LS120 and USB-ZIP Other ATAPI = for ATAPI devices not supported by other HDD features.
Cylinders	1 to 65,536	Number of cylinders.
Heads	1 to 256	Number of read/write heads.
Sectors	1 to 63	Number of sectors per track.
Maximum Capacity	N/A	Displays the calculated size of the drive in CHS.
Total Sectors	N/A	Number of total sectors in LBA mode.
Maximum Capacity	N/A	Displays the calculated size of the drive in LBA.
Multi-Sector Transfer	<b>Disabled</b> 2 sectors 4 sectors 8 sectors 16 sectors	Any selection except Disabled determines the number of sectors transferred per block. The standard is one sector per block.
LBA Mode Control	<b>Disabled</b> Enabled	Enabling LBA causes Logical Block Addressing to be used in place of CHS.
32-Bit I/O	<b>Disabled</b> Enabled	Enables 32-bit communication between CPU and IDE card. Requires PCI or local bus.
Transfer Mode	<b>Standard</b> Fast PIO 1 Fast PIO 2 Fast PIO 3 Fast PIO 4 FPIO 3 / DMA 1 FPIO 4 / DMA 2	Selects the method for transferring the data between the hard disk and system memory.
Ultra DMA Mode *	Disabled MOD0 MOD1 MOD2 MOD3 MOD4 MOD5	Selects the UDMA mode to move data to/from the drive. Autotype the drive to select the optimum transfer mode. This feature is autodetected.
SMART Monitoring	Disabled Enabled	Shows whether a disk supports SMART.

**Note:** In the Option column, bold shows default settings.

(\*) The CompactFlash IDE interface is not capable of running UDMA modes. On the 40 pin IDE interface an 80line UDMA 100 cable is required for proper operation in modes UDMA 3 and higher.

## 25.4 Advanced Menu

Feature	Option	Description
▸ Advanced Chipset Control	Sub menu	Opens Advanced Chipset Control sub menu.
▸ PCI/PNP Configuration	Sub menu	Opens PCI/PNP Config sub menu.
▸ Memory Cache	Sub menu	Opens Cache Control sub menu.
▸ I/O Device Configuration	Sub menu	Opens Peripheral Config sub menu.
▸ Keyboard Features	Sub menu	Opens Keyboard Features sub menu.
▸ Hardware Monitor	Sub menu	Shows hardware monitor current state.
▸ Watchdog Settings	Sub menu	Opens Watchdog Config sub menu.
▸ Display Control	Sub menu	Opens Display Control sub menu
▸ Miscellaneous	Sub menu	Opens sub menu with miscellaneous options.

### 25.4.1 Advanced Chipset Control Submenu

Feature	Option	Description
Enable Memory gap	<b>Disabled</b> Enabled	Allows enabling a 1MB memory gap for add-on cards at 15MB
Graphics Engine 1	Disabled <b>Enabled</b>	Enable/Disable Internal Graphics Device.
Graphics Engine 2	Disabled <b>Enabled</b>	Enabled/Disabled Function 1 of the Internal Graphics Device
Graphics Memory	UMA = 1MB, <b>8MB</b> , 16MB, 32MB	Select the amount of main memory that the Internal Graphics Device will use.

**Note:** In the Option column, bold shows default settings.

### 25.4.2 PCI/PNP Configuration Submenu

Feature	Option	Description
Plug & Play OS	No <b>Yes</b>	If your system has a PnP OS (e.g. Win9x) select Yes to let the OS configure PnP devices not required for booting. No allows the BIOS to configure them.
Reset Configuration Data *	<b>No</b> Yes	Yes erases all configuration data in ESCD, which stores the configuration settings for plug-in devices. Select Yes when required to restore the manufacturer's defaults.
Secured Setup Configuration	<b>Yes</b> No	Yes prevents a Plug and Play OS from changing system settings.
▸ PCI Device, Slot #x	Sub menu	Opens sub menu to configure slot x PCI device
PCI IRQ line 1-4 Onboard LAN IRQ line Onboard USB EHCI IRQ line	Disabled <b>Auto Select</b> IRQ3, 4, 5, 7, 9, 10, 11, 12, 14,15	Select IRQs for external PIC interrupts A/B/C/D and the onboard LAN and USB2.0 host controller. Select Auto to let the BIOS assign the IRQ.
▸ PCI/PNP ISA IRQ Resource Exclusion	Sub menu	Opens IRQ Exclusion sub menu.
Default Primary Video Adapter	AGP <b>PCI</b>	In a system with an AGP and a PCI video adapter end user can select the adapter which will be initialized by the BIOS.

**Notes:** In the Option column, bold shows default settings.

(\*) Setting this option to "yes", under certain circumstances, may help to recover from system boot failure or a resource conflict.

### 25.4.3 PCI Device, Slot #x Submenu

Feature	Option	Description
Option ROM Scan	Disabled <b>Enabled</b>	Initialize device expansion ROM.
Enable Master	<b>Disabled</b> Enabled	Enables device in slot as a PCI bus master, not every device can function as a master. Check device documentation.
Latency Timer	<b>Default</b> , 20h, 40h, 60h, 80h, A0h, C0h, E0h	Minimum guaranteed time slice allocated for bus master in units of PCI bus clocks. A high-priority, high-throughput device may benefit from a greater value.

**Note:** In the Option column, bold shows default settings.

### 25.4.4 PCI/PNP ISA IRQ Resource Exclusion Submenu

Feature	Option	Description
IRQ3	<b>Available</b> Reserved	Reserves the specified IRQ for use by legacy ISA devices.
IRQ4	<b>Available</b> Reserved	See above.
IRQ5	<b>Available</b> Reserved	See above.
IRQ7	<b>Available</b> Reserved	See above.
IRQ9 *	<b>Available</b> Reserved	See above.
IRQ10	<b>Available</b> Reserved	See above.
IRQ11	<b>Available</b> Reserved	See above.
IRQ12	<b>Available</b> Reserved	See above.
IRQ14 **	<b>Available</b> Reserved	See above.
IRQ15 **	<b>Available</b> Reserved	See above.

**Notes:** In the Option column, bold shows default settings.

(\*) IRQ9 is used for SCI in ACPI mode. Do not use IRQ9 for legacy ISA devices when ACPI enabled.

(\*\*) Entry is only visible when primary IDE or secondary IDE is disabled.

### 25.4.5 Memory Cache Submenu

Feature	Option	Description
Memory Cache	Disabled <b>Enabled</b>	Enables or Disables L2 cache.
Cache System BIOS area	Uncached <b>Write Protected</b>	Controls caching of System BIOS area.
Cache Video BIOS area	Uncached <b>Write Protected</b>	Controls caching of Video BIOS area.
Cache Base 0-512K	Uncached Write Through Write Protected <b>Write Back</b>	Controls caching of base memory up to 512KB.
Cache Base 512-640K	Uncached Write Through Write Protected <b>Write Back</b>	Controls caching of base memory above between 512 and 640KB.
Cache Extended Memory area	Uncached Write Through Write Protected <b>Write Back</b>	Controls caching of system memory above 1MB.
D000 – D3FF D400 – D7FF D800 – DBFF DC00 – DFFF	<b>Disabled</b> Write Through Write Protected Write Back	Disabled: block is not cached. Write-Through: Write are cached and sent to main memory at once. Write-Protect: Writes are ignored. Write-Back: Writes are cached but not sent to main memory until necessary.

**Note:** In the Option column, bold shows default settings.

### 25.4.6 I/O Device Configuration Submenu

Feature	Option	Description
Local Bus IDE adapter	Disabled Primary Secondary <b>Both</b>	Enables onboard PCI IDE device.
Hard Disk Pre-Delay:	Disabled 3 Seconds 6 Seconds 9 Seconds 12 Seconds 15 Seconds 21 Seconds 30 Seconds	Adds a delay before the first access of a hard disk by the BIOS. Some hard disks hang if accessed before they have initialized themselves. This delay ensures the hard disk has initialized after power up, prior to being accessed.
Primary IDE UDMA66/100:	Disabled Enabled	Disabled limits max. transfer mode to UDMA33. Enabled allows UDMA66 and above.
Secondary IDE UDMA66/100:	Disabled Enabled	Disabled limits max. transfer mode to UDMA33.

		Enabled allows UDMA66 and above.
USB Options	Sub menu	Opens USB Config sub menu.
AC97 Audio Controller	<b>Disabled</b> Enabled	Enables the AC97 Audio device.
Lan Options	Sub menu	Opens LAN Config sub menu.
SIO Options	Sub menu	Opens Super-IO Config sub menu.

### 25.4.7 USB Options

Feature	Option	Description
USB UHCI Host Controller 1	<b>Enabled</b> Disabled	Enable / Disable UHCI 1 Host Controller for USB ports 0 and 1 (EPIC front).
USB UHCI Host Controller 2	Enabled <b>Disabled</b>	Enable / Disable UHCI 2 Host Controller for USB ports 2 and 3 (EPIC front).
USB EHCI Host Controller *	Disabled <b>Enabled</b>	Controls USB 2.0 functionality.
Legacy USB Support **	Disabled <b>Enabled</b>	Enable support for USB keyboard and mice and boot from USB mass storage devices.

**Notes:** In the Option column, bold shows default settings.

(\*) The USB ports are multiplexed between UHCI and EHCI. Ports are routed to EHCI if an USB 2.0 high-speed device is connected and an EHCI driver is loaded.

(\*\*) If you want to use the USB boot feature, enable USB BIOS Legacy Support. A 16kb UMB area (most likely DC000h-DFFFFh) is used for USB BIOS Legacy Support.

### 25.4.8 LAN Options

Feature	Option	Description
LAN MAC address		Displays adapter's MAC address
Onboard LAN Controller	Disabled <b>Enabled</b>	Enables the ICH4 internal LAN controller.
Onboard LAN PXE ROM	<b>Disabled</b> Enabled	Enables the remote boot BIOS extension for the onboard LAN controller.
Enable WOL	<b>Disabled</b> Enabled	Enables the wake on LAN BIOS extension for the onboard LAN controller.

### 25.4.9 SIO Options

Feature	Option	Description
Floppy disk controller	Disabled <b>Enabled</b>	Enable / Disable the onboard FDC controller.
Serial port A	Disabled Enabled <b>Auto</b>	Disabled turns off the port. Enabled requires end user to enter the base I/O address and the IRQ. Auto makes the BIOS configure the port.
Serial port B	Disabled Enabled	Disabled turns off the port. Enabled requires end user to enter the base I/O address and

	<b>Auto</b>	the IRQ. Auto makes the BIOS configure the port.
Mode	<b>Normal</b> , IR	Set the mode for Serial Port B.
Serial port C	<b>Disabled</b> Enabled Auto	Disabled turns off the port. Enabled requires end user to enter the base I/O address and the IRQ. Auto makes the BIOS configure the port.
Serial port D	<b>Disabled</b> Enabled Auto	Disabled turns off the port. Enabled requires end user to enter the base I/O address and the IRQ. Auto makes the BIOS configure the port.
Interface	<b>RS232</b> , RS485	Set the mode for Serial Port D.
Base I/O address	3F8h, 2F8h, 3E8h, 2E8h, 220h, 228h	Select I/O base of port.
IRQ	IRQ 3, IRQ 4, IRQ10, IRQ11	Select IRQ
Parallel Port	Disabled Enabled <b>Auto</b>	
Mode	Output only <b>Bi-directional</b> EPP ECP EPP & ECP	Set the mode for Parallel Port
Base I/O address	<b>378h</b> , 278h, 3BCh	Select I/O base of port.
Interrupt	IRQ 5, <b>IRQ 7</b>	Select IRQ
DMA channel	DMA1, <b>DMA3</b>	Set the DMA channel for the parallel port in ECP mode

**Note:** In the Option column, bold shows default settings.

## 25.4.10 Keyboard Features Submenu

Feature	Option	Description
Numlock	Auto <b>On</b> Off	On or Off turns NumLock on or off at boot up. Auto turns NumLock on if it finds a numeric key pad.
Key Click	<b>Disabled</b> Enabled	Turns audible key click on.
Keyboard auto-repeat rate	<b>30/sec</b> , 26.7/sec, 21.8/sec, 18,5/sec, 13.3/sec, 10/sec, 6/sec, 2/sec	Sets the number of times to repeat a keystroke per second if you hold the key down.
Keyboard auto-repeat delay	$\frac{1}{4}$ sec, <b><math>\frac{1}{2}</math> sec</b> , $\frac{3}{4}$ sec, 1 sec	Sets the delay time after the key is held down before it begins to repeat the keystroke.

**Note:** In the Option column, bold shows default settings.

### 25.4.11 Hardware Monitor Submenu

This submenu shows the current voltages, temperatures and the fan speed of the system.

Voltage/Temperature/Fan	Explanation
VCC 3.3V Voltage	3.3V power plane
CPU Core Voltage	CPU core voltage
5Vsb Voltage	5V-Standby voltage
Battery Voltage	Battery voltage
CPU Temperature	CPU Temperature in °C and °F
CPU Fan Speed	CPU fan speed in rpm

### 25.4.12 Watchdog Settings Submenu

Feature	Option	Description
Mode	<b>Disabled</b> Reset NMI	Select watchdog operation mode.
Delay	1s, 5s, 10s, <b>30s</b> , 1min, 5.5min, 10.5min, 30.5min	The time until the watchdog counter starts counting. Useful to handle longer boot times.
Timeout	1s, 5s, 10s, <b>30s</b> , 1min, 5.5min, 10.5min, 30.5min	Max. trigger period.

**Note:** In the Option column, bold shows default settings.

### 25.4.13 Display Control Submenu

Feature	Option	Description
Display Mode	CRT only LFP only <b>CRT+LFP</b>	Select the display mode.
JDA Revision	x.x	Displays the revision of the JILI data area image.
Flat Panel Type	VGA * SVGA * XGA * XGA2 * SXGA * UXGA * Enter PAID Enter FPID <b>Auto</b>	Select Auto to let the BIOS automatically detect the panel type or use one of the predefined fixed panel types.  Choose Enter PAID or Enter FPID to manually set JILI3 ID values.
PAID/FPID **	0 – FFFF, default <b>0</b>	Enter the JILI3 ID.
Flat Panel Scaling	Centered <b>Stretched</b>	Stretched expands a low resolution video mode to full screen on a higher flat panel resolution.
Flat Panel Backlight ***	0 – 255, default <b>128</b>	Enter a value to adjust backlight of the LCD.
Flat Panel Contrast ****	0 – 63, default <b>32</b>	Enter a value to adjust contrast of the LCD.

**Note:** In the Option column, bold shows default settings.

(\*) Standard timings for VGA to UXGA panels cannot drive all available displays of that type that are on

the market. Use a JILI cable whenever possible.

(\*\*) Only visible if Enter PAID or Enter FPID is selected.

(\*\*\*) Only visible if the panel adapter is equipped with a MAX5362 DAC for backlight control.

(\*\*\*\*) Only visible if the panel adapter is equipped with a Xicore X9429 digital potentiometer for contrast control.

## 25.4.14 Miscellaneous Submenu

Feature	Option	Description
Floppy Check	<b>Disabled</b> Enabled	Enabled verifies floppy type on boot; disabled speeds boot.
Summary Screen	<b>Disabled</b> Enabled	If enabled, a summary screen is displayed just before booting the OS to let the end user see the system configuration.
QuickBoot Mode	Disabled <b>Enabled</b>	Allows the system to skip certain tests while booting. This will decrease the time needed to boot the system.
Extended Memory Testing	Normal * <b>Just zero it</b> None	Determines which type of tests will be performed on memory above 1MB.
Dark Boot	<b>Disabled</b> Enabled	If enabled, system comes up with a blank screen instead of the diagnostic screen during bootstrap.
Halt On Errors	<b>Yes</b> No	Determines if post errors cause the system to halt.
PS/2 Mouse	<b>Auto Detect</b> Enabled Disabled	Selecting Disabled prevents any installed PS/2 mouse from functioning but frees up IRQ12. Selecting Autodetect frees IRQ12 if a mouse is not detected.
Large Disk Access Mode	<b>DOS</b> Other	Select DOS if you have DOS. Select Other if you have another OS such as UNIX. A large disk is one that has more than 1024 cylinders, more than 16 heads or more than 63 sectors per track.
Spread Spectrum	<b>Disable</b> Enable	Controls the spread spectrum feature of the clock generator

**Note:** In the Option column, bold shows default settings.

(\*) The option normal is not visible when QuickBoot is enabled.

### Dark Boot

After you turn on or reset the computer, Dark Boot displays a graphical logo (default is a blank screen) instead of the text based POST screen, which displays a number of PC diagnostic messages.

The graphical logo stays up until just before the OS loads unless:

- You press <Esc> to display the POST screen
- You press <F2> to enter Setup
- POST issues an error message
- The BIOS or an option ROM requests keyboard input

## 25.5 Security Menu

Feature	Option	Description
Supervisor Password is	<b>Clear</b> Set	Displays whether password is set.
User Password is	<b>Clear</b> Set	Displays whether password is set.
Set User Password *	Up to seven alphanumeric characters	Pressing <Enter> displays the dialog box for entering the user password. In related systems, this password gives restricted access to setup.
Set Supervisor Password *	Up to seven alphanumeric characters	Pressing <Enter> displays the dialog box for entering the user password. In related systems, this password gives full access to setup.
Diskette access	User <b>Supervisor</b>	Enabled requires supervisor password to access floppy disk.
Fixed disk boot sector	<b>Normal</b> Write protected	Write protect the boot sector on the hard disk for virus protection. Requires a password to format or Fdisk the hard disk.
Virus check reminder	<b>Disabled</b> Daily Weekly Monthly	Displays a message during bootup asking (Y/N) if you backed up the system or scanned for viruses. Message returns on each boot until you respond with Y. Daily displays the message on the first boot of the day, Weekly on the first boot after Sunday, and monthly on the first boot of the month.
System backup reminder	<b>Disabled</b> Daily Weekly Monthly	Displays a message during bootup asking (Y/N) if you backed up the system or scanned for viruses. Message returns on each boot until you respond with Y. Daily displays the message on the first boot of the day, Weekly on the first boot after Sunday, and monthly on the first boot of the month.
Password on bootmenu:	<b>Disabled</b> Enabled	Enables password entry on bootmenu
Password on boot	<b>Disabled</b> Enabled	Enabled requires a password on boot. Requires prior setting of the supervisor password. If supervisor password is set and this option is disabled, BIOS assumes user is booting.

**Notes:** In the Option column, bold shows default settings.

(\*) Enabling Supervisor Password requires a password for entering Setup. Passwords are not case sensitive. User and Supervisor passwords are related. A User password is possible only if a Supervisor password exists.

## 25.6 Power Menu

In the BIOS Setup Utility, you can set up an Advance Power Management system (APM 1.2) to reduce the amount of energy used after specified periods of inactivity. The setup menu supports:

- Full On State
- Standby State with Partial Power Reduction
- Suspend State with Full Power Reduction

In addition you can enable an ACPI 1.0 support in the BIOS setup utility, if you intend to use an operating system supporting the Advanced Configuration and Power Management Interface. For logical reasons it is required to use an ATX power supply with the ACPI feature.

The following states are supported from the system:

- S0 (Working)
- S1 (Sleeping with processor context maintained)
- S3 (Suspend to RAM)
- S5 (Soft off)

The state S2 (sleeping with processor context not maintained) is not supported. The state S4 (Save to Disk) is a matter of the used operating system.

### 25.6.1 ACPI Resume Events

The following events resume the system from S1:

- Power button
- PME#
- PS/2 keyboard and mouse
- USB keyboard and mouse activity
- USB resume event

The following events resume the system from S3:

- Power button

Feature	Option	Description
Enable ACPI *	No <b>Yes</b>	Enables/Disables ACPI BIOS (Advanced Configuration and Power Interface). IRQ9 is used for SCI (System Control Interrupt).
▸ ACPI Control	sub menu	Opens the ACPI sub menu
▸ Thermal Management	sub menu	Opens the Thermal Management sub menu
Max CPU frequency **	1800MHz 1600MHz 1400MHz <b>1200MHz</b> 1000MHz 800MHz	<b>Warning!</b> Selecting frequencies higher than the default may cause the system to reach "critical trip point" and shut down if a proper cooling solution is not used. Always ensure that you use proper cooling when selecting higher frequency

	600MHz	settings.
Automatic Thermal Monitor Control Circuit **	Disabled TM1 <b>TM2 ***</b>	Enables the thermal control circuit (TCC) of the thermal monitor feature of the Pentium-M CPU. TM1 = 50% duty cycle TM2 = Geyserville III <b>Automatic TTC must be enabled to ensure that the processor operates within specification.</b>
Hard Disk Timeout	<b>Disabled</b> , 10 sec – 15 min	Inactivity period of hard disk required before standby (motor off).
Video Timeout	<b>Disabled</b> , 10 sec – 15 min	Inactivity period of user input device before the screen is turned off.
Resume on Modem Ring	<b>Off</b> On	Enabled wakes the system on incoming calls detected by mode (RI).
Resume on Time	<b>Off</b> On	Enabled wakes the system at a specific time.
Resume Time	00:00:00	Specifies the time when the system is to wake.
Power supply	<b>ATX</b> AT	Specifies whether an ATX or an AT power supply is used.
Power Button Function	Power Off <b>Sleep</b>	Determines if the system enters suspend or soft off when the power button is pressed.
Power Loss Control	Stay Off Power On <b>Last State</b>	Determines how the system behaves after a power failure. This only works in conjunction with a CMOS backup battery.

**Notes:** In the Option column, bold indicates default setting.

(\*) Disable ACPI support whenever you are using an operating system without ACPI capability.

(\*\*) See the chapter "Important Technology Information of this user's guide for more details about these features.

(\*\*\*) coolMONSTER/PM with Celeron M processor does not support TM2.

## 25.6.2 ACPI Control Submenu

Feature	Option	Description
APIC – IO APIC Mode *	<b>Disabled</b> Enabled	This item is valid only for Windows XP. Also, a fresh install of the OS must occur when APIC Mode is desired. Test the IO APIC by setting an item to Enabled. The APIC Table will then be pointed to by the RSDT, the Local APIC will be initialized, and the proper enable bits will be set in IHC4M. See section 14.1
Native IDE Support *	<b>Disabled</b> Enabled	Enable Native IDE support for WINXP by setting this item. The NATA Package will be created if this item is set to Enabled. Changing this item will have no effect in WIN98, WINME, or WIN2K. See section 13.2 for more details.
Deepest sleep state for standby:	None S1 <b>S3</b>	This option chooses ACPI sleep states. Using S3cold saves more power than S3hot, which saves more than S1. If choosing 'None' the OS will not offer any standby. Please be sure your board supports the appropriate S3

		state when making this choice.
Mars ACPI Support	<b>Disabled</b> Enabled	This enable the Mars ACPI support. This allows windows to display the Mars smart battery info

**Notes:** In the Option column, bold indicates default setting.

(\*) See the chapter "Important Technology Information of this user's guide for more details about these features.

### 25.6.3 Thermal Management Submenu

Feature	Option	Description
Active Trip Point *	Disabled 40 C – 100 C	Determines the temperature of the ACPI Active Trip Point, the point at which the OS will turn on/off the CPU fan.
Passive Trip Point *	Disabled 40 C – 100 C	Determines the temperature of the ACPI Passive Trip Point, the point at which the OS will turn on/off CPU clock throttling.
Critical Trip Point *	40 C – 110 C	This value controls the temperature of the ACPI Critical Trip Point- the point at which the OS will shut the system off.
Temp Zone1(Cpu)		Logical Temperature
Min Fan Trip Temp	<b>40 C</b> 0 C - 124 C	This is the temperature in degrees celcius at which the fan is started
Max Fan Trip Temp	<b>80 C</b> 0 C - 124 C	This is the critical temperature in degrees celcius when the fan is at full speed
Temp Zone2(Chassi)		Logical Temperature
Min Fan Trip Temp	<b>40 C</b> 0 C - 124 C	This is the temperature in degrees celcius at which the fan is started
Max Fan Trip Temp	<b>80 C</b> 0 C - 124 C	This is the critical temperature in degrees celcius when the fan is at full speed
Fan Min Duty Cycle	<b>80</b> 0-255	This is the minimum speed at which the fan will rotate (value may be set between 70 and 255)
Fan 1 Control Method	<b>Auto Cpu</b> Auto Chassis Auto Cpu/Chassis Fan Disabled Full On	Set the fan Control mode options: Full On Fan Is always on Auto Fan runs with variable duty cycle

## 25.7 Boot Menu and Utilities

MultiBoot is a boot utility integrated in the PhoenixBIOS 4.0. The coolMONSTER/PM provides the MultiBoot XP version with integrated Boot First function.

### 25.7.1 MultiBoot XP

MultiBoot XP comes with a complete new look of the Boot Device Priority submenu. This submenu is now separated into two sections:

- Boot Priority Order
- Excluded from Boot Order

MultiBoot XP can display the setup menus by each kind of device type and arrange the boot priority order with any sequence of devices. MultiBoot XP meets the requirements of PC 98 and accommodates more devices that are bootable. It employs a boot scheme that is generic and flexible enough to boot from any current device. You can select your boot device in Setup, or you can choose a different device each time you boot by selecting your boot device in the Boot First function.

An available bootable device can be easily switched between the two sections by just highlighting the device and then pressing <X>. To change the order, select the device to change and press <-> to decrease or <+> to increase priority. You can also choose between four default configurations for the boot order <1>-<4>.

#### Boot Priority Order

This section shows eight configuration entries for up to eight devices that can be arranged in boot priority order (1: highest priority, 8: lowest priority).

#### Excluded from Boot Order

This section shows all devices that are excluded from the boot order. Any device listed here will never be used as boot device and not appear in the Boot First function.

The following table shows a list of supported devices:

Device	Description
IDE 0	Primary master IDE hard drive
IDE 1	Primary slave IDE hard drive
IDE 2	Secondary master IDE hard drive
IDE 3	Secondary slave IDE hard drive
IDE CD	IDE compatible CD-ROM drive
Legacy Floppy Drives	Standard Legacy Diskette Drive
USB KEY	USB Stick
USB FDC	USB Diskette Drive
USB HDD	USB Hard Drive and memory sticks that follow MMS specification
USB CDR0M	USB CD-ROM Drive
USB ZIP	USB ZIP Drive
USB LS120	USB LS120 Drive
PCI BEV	Ethernet Controller on the PCI Bus with LAN Boot ROM
PCI SCSI	SCSI Controller on the PCI Bus with SCSI BIOS ROM

## 25.7.2 Boot First Function

Display the Boot First function by pressing <Esc> during POST. In response, the BIOS displays the message Entering Boot Menu and then displays the Boot Menu at the end of POST. With the MultiBoot XP feature only devices detected during boot up are displayed.

Use the menu to select a following option:

- Override the existing boot sequence (for this boot only) by selecting another boot device. If the specified device does not load the OS, the BIOS reverts to the previous boot sequence.
- Enter Setup.
- Press <Esc> to continue with the existing boot sequence.

## 25.8 Exit Menu

The following sections describe the five options in Exit Menu. Pressing <Esc> does not exit this menu. You must select an item from the menu to exit.

Feature	Option	Description
Exit Saving Changes	Saves selections and exits setup. The next time the system boots, the BIOS configures the system according to the Setup selection stored in CMOS.	Exit saving changes.
Exit Discarding Changes	Exits Setup without storing in CMOS any new selections you may have made. The selections previously in effect remain in effect.	Exit discarding changes.
Load Setup Defaults	Displays default values for all the Setup menus.	Load setup defaults.
Discard Changes	If, during a Setup session, you change your mind about changes you have made and have not yet saved the values to CMOS, you can restore the values you saved to CMOS.	Discard changes.
Save Changes	Saves all the selection without exiting Setup. You can return to the other menus to review and change your selection.	Save changes.

## 25.9 Kontron BIOS Extensions

Besides the Phoenix System BIOS, the coolMONSTER/PM comes with a few BIOS extensions that support special features. All extensions are located in the onboard flash EEPROM. Some extensions are permanently available; some are loaded if required during boot up. Supported features include:

- JIDA standard
- Remote Control (JRC)
- Onboard LAN RPL ROM

All enabled BIOS extensions require shadow RAM. They will be loaded into the same 32K shadowed memory block, if possible. However, if the system memory cannot find free memory space because all the memory is already used for add-on peripherals, the BIOS extensions do not load.

### 25.9.1 JIDA BIOS extension

The JUMPtect Intelligent Device Architecture (JIDA) BIOS extension is not a true extension BIOS. It is part of the system BIOS and is located in the system BIOS segments after boot up. It is permanently available and supports the JIDA 16-bit and JIDA 32-bit standard.

The JIDA 16-bit standard is a software interrupt 15hex driven programmers interface and offers lots of board information functions. For detailed information about programming, refer to the JIDA specification and a source code example (JIDAI???.ZIP), which you can find at the Kontron Web site. The three question marks represent the revision number of the file. You also can contact technical support for this file.

For other operating systems, special 32-bit drivers (JIDAIA??.ZIP) are available. You can download the zip file from the Kontron Web site.

### 25.9.2 Remote Control Client Extension

You can remotely control the coolMONSTER/PM using software available from Kontron (JRC-1, Part Number 96047-0000-00-0). This software tool can communicate with the board via one of the serial ports. During boot-up, the system BIOS scans the serial ports for an available JRC connection. If detected, it loads the JRC client BIOS extension into the memory. With the JRC client loaded into the first detected free memory location between C0000hex and DFFFFhex, a 16K block is shadowed.

For more information on the Remote Control usage, refer to the JRC-1 technical manual or Application Note JRCUsage\_E??.PDF, which you can find on the Kontron Web site.

### 25.9.3 LAN PXE ROM

If the onboard LAN PXE ROM is enabled in the system BIOS setup, a special optional ROM for the Ethernet controller loads into memory during boot up. This optional ROM allows you to boot the coolMONSTER/PM over an Ethernet connection. A server with Intel PXE boot support is required on the other side of the Ethernet connection. The setup and configuration of the server, including PXE support, is not the responsibility of Kontron. The PXE ROM extension is loaded into the first free memory area between C0000hex and DFFFFhex and a 16K block of memory is shadowed.

## 25.10 Updating or Restoring BIOS Using PhoenixFlash

PhoenixFlash allows you to update the BIOS by using a floppy disk without having to install a new ROM chip. PhoenixFlash is a utility used to flash a BIOS to the Flash ROM installed on the coolMONSTER/PM.

Use PhoenixFlash to:

- Update the current BIOS with a newer version
- Restore a corrupt BIOS

### 25.10.1 Flashing a BIOS

Use the following procedure to update or restore a BIOS.

- Download the Phoenix Flash compressed file, CRDxLEUB.ZIP, from the KONTRON Embedded Modules Web site or contact your local technical support for it. It contains the following files:

File	Purpose
MAKEBOOT.EXE	Creates the custom boot sector on the Crisis Recovery Diskette.
CRISBOOT.BIN	Serves as the Crisis Recovery boot sector code.
MINIDOS.SYS	Allows the system to boot in Crisis Recovery Mode.
PHLASH16.EXE	Programs the flash ROM.
WINCRIS.EXE	Creates the Crisis Recovery Diskette from Windows.
WINCRIS.HLP	Serves as the help file of WINCRISSES.EXE.
CRISDISK.BAT	Batch file for crisis disk.
BIOS.WPH	Serves as the actual BIOS image to be programmed into Flash ROM.

- Install Phoenix Flash on a hard disk by unzipping the content of CRDxLEUB.ZIP into a local directory such as C:\PHLASH.
- Create a Crisis Recovery Diskette by inserting a blank diskette into Drive A: or B: and execute WINCRISIS.EXE. This at least copies three files onto the diskette.

File	Purpose
MINIDOS.SYS	Allows the system to boot in Crisis Recovery Mode.
PHLASH16.EXE	Programs the flash ROM.
BIOS.ROM	Serves as the actual BIOS image to be programmed into Flash ROM.

- If the BIOS image (BIOS.ROM) changes due to an update or bug fix, copy the new BIOS onto the diskette and name it BIOS.ROM.

Phoenix Flash runs in either command line mode or crisis recovery mode.

- Use the command line mode to update or replace a BIOS. To execute Phlash in this mode, move to the Crisis Recovery Disk and type:

*PHLASH16 <bios name>*      (Example: *PHLASH16 LEUBR110.WPH*)

PhoenixPhlash will update the BIOS. PhoenixPhlash can fail if the system uses memory managers. If this occurs, the utility displays the following message:

*Cannot flash when memory manager are present.*

If you see this message after you execute Phlash, disable the memory manager or use parameter /x for Phlash16.exe.

*PHLASH16 /X <bios name>*

### 25.10.2 Preventing Problems When Updating or Restoring BIOS


Updating the BIOS represents a potential hazard. Power failures or fluctuations can occur when you update the Flash ROM can damage the BIOS code, making the system unbootable.

To prevent this hazard, many systems come with a boot-block Flash ROM. The boot-block region contains a fail-safe recovery routine. If the boot-block code finds a corrupted BIOS (checksum fails), it boots into the crisis recovery mode and loads a BIOS image from a crisis diskette (see above).

Additionally, the end user can insert an update key into the parallel port (LPT) to force initiating the boot block recovery routine.


For further information on the update key and the crisis diskette, see the Application Note PHLASH\_SCE???, which is available from the KONTRON Embedded Modules Web site. The three question marks stand for the revision number of the file.

## 26 Appendix C: Block Diagram




# 27 Appendix D: Mechanical Dimensions

## 27.1 Top View




Dimensions on Mounting Holes and Pin 1 of each connector given in mm (mil).

## 27.2 Slot View




# 28 Appendix E: Connector Layout

## 28.1 Top Side



**Notes:** The position of Pin 1 of each connector can be seen in the previous chapter.

### 28.2 Bottom Side



## 28.3 Connector Functions and Interface Cables

The table notes connector functions, as well as mating connectors and available cables.

Connector	Function	Mating Connector	Available Cable or Accessory	Description
X1	DVO Connector			For DVO Interfacing
X3	USB Connector	Standard USB plug		For USB device connection
X4	Primary IDE Hard Disk Interface Connector	2.54mm 40 pos. (AMP 4-215882-0 or compatible)	KAB-IDE-1 (PN 96022-0000-00-0)	For 3.5" HDD
X6	Secondary IDE Hard Disk Interface Connector	2mm 44 pos. (Berg 89361-144 or compatible)	KAB-IDE-25 (PN 96020-0000-00-0) or KAB-IDE-2MM (PN 96021-0000-00-0)	For 3.5" HDD or 2.5" HDD.
X7	Ethernet Connector	Standard RJ45 plug		For Ethernet connection
X8	Sound Connector	2.54mm 6 pos. (JST XHP-6 with crimp contacts JST SXH-001T-P0.6 Or JST SXH-002T-P0.6)	KAB-SOUND-CMP (PN96063-0000-00-0)	Cable with open ends
X9	CRT Connector	Standard DSUB15 male plug		For CRT monitor connection
X10	JILI LVDS Interface		KAB-JILI-????? (see separate cable list)	For JILI interface cables
X11	Parallel Interface LPT Connector	2.54mm 26 pos. (AMP 2-215882-6 or compatible)	KAB-DSUB25-1 (PN 96015-0000-00-0)	For DSUB 25 adaptation.
X12	Feature	2.54mm 26 pos. (AMP 2-215882-6 or compatible)		
X13	USB Connector	Standard USB plug		For USB device connection
X14	Floppy Drive Interface Connector	2.54mm 34 pos. (AMP 3-215882-4 or compatible)	KAB-FLOPPY-1 (PN 96018-0000-00-0)	For 3.5" floppy
X15	PS/2 Mouse Interfaces	Standard PS/2 plugs		For PS/2 Mouse
X16	PS/2 Keyboard Interfaces	Standard PS/2 plugs		For PS/2 Keyboard
X17	RS485 Interface Connector (COM D)	2.54mm 5 pos. (JST XHP-5 with crimp contacts JST SXH-001T-P0.6 or JST SXH-002T-P0.6)		
X18, X19, X20, X21	Serial Interface Connectors (COM A -D)	2.54mm 10 pos. (AMP 1-215882-0 or compatible)	KAB-DSUB9-2 (PN 96017-0000-00-0)	For DSUB 9 adaptation.
X23	Power Connector	3.96mm 5 pos. (Molex SPOX 09-50-1051 with crimp contacts MOLEX SPOX 08-70-1028)		
X24	Fan Connector	2.54mm 3 pos. (AMP MTA-100 3-640440-3 or compatible)		For CPU Fan connection

## 28.4 Pin-out Table

Pin	COM A - COM D	COM D RS485	LPT	Floppy	Primary IDE	Secondary IDE	Feature	CRT
	X18-X21	X17	X11	X14	X4	X6	X12	X9
1	DCD	485_1RXD+	/STB	GND	HDRSTJ	HDRSTJ	KBCLK	RED
2	DSR	485_1RXD-	/AFD	RPM	GND	GND	MSCLK	GRN
3	SIN	GND	PD0	GND	PIDE_D7	SIDE_D7	KBDAT	BLU
4	RTS	485_1TXD+	/ERR	NC	PIDE_D8	SIDE_D8	MSDAT	NC
5	SOUT	485_1TXD-	PD1	GND	PIDE_D6	SIDE_D6	VCC *	GND
6	CTS		/INIT	NC	PIDE_D9	SIDE_D9	NC	GND
7	DTR		PD2	GND	PIDE_D5	SIDE_D5	NC	GND
8	RI		/SLIN	INDEXJ	PIDE_D10	SIDE_D10	GND	GND
9	GND		PD3	GND	PIDE_D4	SIDE_D4	H_LED	NC
10	VCC *		GND	MTR0J	PIDE_D11	SIDE_D11	NC	GND
11			PD4	GND	PIDE_D3	SIDE_D3	NC	NC
12			GND	DR1J	PIDE_D12	SIDE_D12	SPEAKER	DDA
13			PD5	GND	PIDE_D2	SIDE_D2	NC	HSYNC
14			GND	DR0J	PIDE_D13	SIDE_D13	NC	VSYNC
15			PD6	GND	PIDE_D1	SIDE_D1	GND	DCK
16			GND	MTR1J	PIDE_D14	SIDE_D14	RESIN	
17			PD7	GND	PIDE_D0	SIDE_D0	NC	
18			GND	FDIR	PIDE_D15	SIDE_D15	NC	
19			/ACK	GND	GND	GND	5V SB	
20			GND	STEPJ	NC	NC	LILED	
21			/BUSY	GND	PIDE_DRQ	SIDE_DRQ	PS_ON	
22			GND	WDATAJ	GND	GND	SPEEDLED	
23			PE	GND	PIDE_IOWJ	SIDE_IOWJ	PWRBTN	
24			GND	WGATEJ	GND	GND	ACTLED	
25			/SLCT	GND	PIDE_IORJ	SIDE_IORJ	USB2-	
26			VCC *	TRK0J	GND	GND	USB2+	
27				GND	PIDE_RDY	SIDE_RDY		
28				WRTPTJ	PRI_PD1	SEC_PD1		
29				GND	PIDE_AKJ	SIDE_AKJ		
30				RDATAJ	GND	GND		
31				GND	SIRQI	SIRQII		
32				HDSEL	NC	NC		
33				GND	PIDE_A1	SIDE_A1		
34				DSKCHG	CBLID	NC		
35					PIDE_A0	SIDE_A0		
36					PIDE_A2	SIDE_A2		
37					PIDE_CS1J	SIDE_CS1J		
38					PIDE_CS3J	SIDE_CS3J		
39					DASP_P	DASP_S		
40					GND	GND		
41						VCC *		
42						VCC *		
43						GND		
44						NC		

Pin	Ethernet	Sound	PS/2 Keyboard	PS/2 Mouse	USB 1	USB 2	Power	Fan
	X7	X8	X16	X15	X13	X3	X23	X24
1	TXD+	RECHTS	KBDAT	MSDAT	USB_5V	USB_5V	+12V *	Sense
2	TXD-	ASGND	MSDAT	NC	USB-	USB-	VCC *	5V *
3	RXD+	LINKS	KEYGND	KEYGND	USB+	USB+	VCC *	GND
4	NC **	AUXAR_C	KEYVCC *	KEYVCC *	USB_GND	USB_GND	GND	
5	NC **	MIC_C	KBCLK	MSCLK			GND	
6	RXD-	AUXAL_C	MSCLK	NC				
7	NC **							
8	NC **							

---

**Notes:** (\*) To protect the external power lines of peripheral devices, make sure that:

- the wires have the right diameter to withstand the maximum available current
- the enclosure of the peripheral device fulfils the fire-protecting requirements of IEC/EN 60950.

(\*\*) Do not connect anything to these signals.

(\*\*\*) The internal USB port 3 is not protected on the power lines. An additional resettable fuse is recommended.

---

## 29 Appendix F: PC Architecture Information

The following sources of information can help you better understand PC architecture.

### 29.1 Buses

#### 29.1.1 PISA

- PISA Bus Specification Version 1.7 June 1997

#### 29.1.2 ISA, Standard PS/2 - Connectors

- AT Bus Design: Eight and Sixteen-Bit ISA, E-ISA and EISA Design, Edward Solari, Annabooks, 1990, ISBN 0-929392-08-6
- AT IBM Technical Reference Vol 1&2, 1985
- ISA & EISA Theory and Operation, Edward Solari, Annabooks, 1992, ISBN 0929392159
- ISA Bus Specifications and Application Notes, Jan. 30, 1990, Intel
- ISA System Architecture, Third Edition, Tom Shanley and Don Anderson, Addison-Wesley Publishing Company, 1995, ISBN 0-201-40996-8
- Personal Computer Bus Standard P996, Draft D2.00, Jan. 18, 1990, IEEE Inc
- Technical Reference Guide, Extended Industry Standard Architecture Expansion Bus, Compaq 1989

#### 29.1.3 PCI

- PCI SIG  
The PCI-SIG provides a forum for its ~900 member companies, who develop PCI products based on the specifications that are created by the PCI-SIG. You can search for information about the SIG on the Web.
- PCI & PCI-X Hardware and Software Architecture & Design, Fifth Edition, Edward Solari and George Willse, Annabooks, 2001, ISBN 0-929392-63-9.
- PCI System Architecture, Tom Shanley and Don Anderson, Addison-Wesley, 2000, ISBN 0-201-30974-2.

### 29.2 General PC Architecture

- Embedded PCs, Markt&Technik GmbH, ISBN 3-8272-5314-4 (German)
- Hardware Bible, Winn L. Rosch, SAMS, 1997, 0-672-30954-8
- Interfacing to the IBM Personal Computer, Second Edition, Lewis C. Eggebrecht, SAMS, 1990, ISBN 0-672-22722-3
- The Indispensable PC Hardware Book, Hans-Peter Messmer, Addison-Wesley, 1994, ISBN 0-201-62424-9

- The PC Handbook: For Engineers, Programmers, and Other Serious PC Users, John P. Choisser and John O. Foster, Annabooks, 1997, ISBN 0-929392-36-1

## 29.3 Ports

### 29.3.1 RS-232 Serial

- EIA-232-E standard  
The EIA-232-E standard specifies the interface between (for example) a modem and a computer so that they can exchange data. The computer can then send data to the modem, which then sends the data over a telephone line. The data that the modem receives from the telephone line can then be sent to the computer. You can search for information about the standard on the Web.
- RS-232 Made Easy: Connecting Computers, Printers, Terminals, and Modems, Martin D. Seyer, Prentice Hall, 1991, ISBN 0-13-749854-3
- National Semiconductor  
The Interface Data Book includes application notes. Type "232" as a search criteria to obtain a list of application notes. You can search for information about the data book on National Semiconductor's Web site.

### 29.3.2 ATA

AT Attachment (ATA) Working Group.

This X3T10 standard defines an integrated bus interface between disk drives and host processors. It provides a common point of attachment for systems manufacturers and the system. You can search for information about the working group on the Web. We recommend you also search the Web for information on *4.2 I/O cable*, if you use hard disks in a DMA3 or PIO4 mode.

### 29.3.3 USB

USB Specification

USB Implementers Forum, Inc. is a non-profit corporation founded by the group of companies that developed the Universal Serial Bus specification. The USB-IF was formed to provide a support organization and forum for the advancement and adoption of Universal Serial Bus technology. You can search for information about the standard on the Web.

## 29.4 Programming

- C Programmer's Guide to Serial Communications, Second Edition, Joe Campbell, SAMS, 1987, ISBN 0-672-22584-0
- Programmer's Guide to the EGA, VGA, and Super VGA Cards, Third Edition, Richard Ferraro, Addison-Wesley, 1990, ISBN 0-201-57025-4
- The Programmer's PC Sourcebook, Second Edition, Thom Hogan, Microsoft Press, 1991, ISBN 1-55615-321-X

- Undocumented PC, A Programmer's Guide to I/O, CPUs, and Fixed Memory Areas, Frank van Gilluwe, Second Edition, Addison-Wesley, 1997, ISBN 0-201-47950-8

## 30 Appendix G: Document Revision History

Version	Date	Edited by	Changes
LEUBM110	03.05.2006	BAJ	Official release
LEUBM111	28.06.2007	SMI	Correction of operating temperature and memory map
LEUBM112	11.07.2007	SMI	Add supply current, correction of Processor specification and Bios settings.
LEUBM113_pre	23.10.2007	GUL	Updated to current Kontron Layout
LEUBM113	21.02.2007	ZDA	Update RAM Module speed